



30813

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 |
| 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 |    |

|      |  |
|------|--|
| X88  | AC connector                                     |
| 31   | Battery -  |
| 30   | Battery +  |
| R62  | CO adjustment resistor                           |
| B54  | Crankshaft position (CKP) sensor                 |
| X1   | Data link connector (DLC)                        |
| A35  | Engine control module (ECM)                      |
| B24  | Engine coolant temperature (ECT) sensor          |
| H63  | Engine malfunction indicator lamp (MIL)          |
| Y104 | Evaporative emission (EVAP) canister purge valve |
| M12  | Fuel pump  |
| F    | Fuse   |
| B72  | Heated oxygen sensor (HO2S)                      |
| Y99  | Idle air control (IAC) valve                     |
| A52  | Ignition amplifier                               |
| T1   | Ignition coil                                    |
| 15   | Ignition switch - ignition ON                    |
| 50   | Ignition switch - start signal                   |
| Y3   | Injector   |
| B25  | Intake air temperature (IAT) sensor              |
| W21  | Octane coding plug                               |
| K46  | Relay module                                     |
| S104 | Throttle position (TP) switch                    |
| A57  | Transmission control module (TCM)                |
| B33  | Vehicle speed sensor (VSS)                       |
| B148 | Volume air flow (VAF) sensor                     |