

1	Camshaft position (CMP) sensor
2	CO adjustment resistor
3	Data link connector (DLC)
4	Engine control module (ECM)
5	Engine control relay
6	Engine coolant temperature (ECT) sensor
7	Engine speed (RPM) sensor
8	Evaporative emission (EVAP) canister purge valve
9	Fuel filter - tank exterior
10	Fuel pressure regulator
11	Fuel pump - in tank
12	Fuel pump relay
13	Heated oxygen sensor (HO2S) - in exhaust
14	Idle speed control (ISC) actuator
15	Ignition coils
16	Injectors
17	Intake air temperature (IAT) sensor
18	Knock sensors (KS)
19	Throttle position (TP) sensor
20	Intake manifold air control solenoid
21	Volume air flow (VAF) sensor

