



| | |
|---------|---|
| A16 | ABS control module |
| K143 | AC compressor clutch relay |
| B161 | AC refrigerant pressure sensor |
| B138 | Accelerator pedal position (APP) sensor |
| B121 | Barometric pressure (BARO) sensor |
| 31 | Battery - |
| 30 | Battery + |
| S13 | Brake pedal position (BPP) switch |
| S258 | Clutch pedal position (CPP) switch |
| CAN | Controller area network (data bus) |
| B54 | Crankshaft position (CKP) sensor |
| X1 | Data link connector (DLC) |
| K46 | Engine control (EC) relay |
| A35 | Engine control module (ECM) |
| K12-I | Engine coolant blower motor relay 1 |
| K12-II | Engine coolant blower motor relay 2 |
| K12-III | Engine coolant blower motor relay 3 |
| K12-IV | Engine coolant blower motor relay 4 |
| B24 | Engine coolant temperature (ECT) sensor |
| B86 | Engine oil level sensor |
| S389 | Engine oil pressure switch |
| Y28 | Exhaust gas recirculation (EGR) solenoid |
| Y151 | Exhaust gas recirculation (EGR) valve actuator |
| B149 | Exhaust gas recirculation (EGR) valve position sensor |
| R64 | Fuel filter heater |
| A107 | Fuel injection pump control module |
| Y132 | Fuel injection timing solenoid |
| Y159 | Fuel quantity adjuster |
| K280 | Fuel quantity adjuster relay |
| Y12 | Fuel shut-off solenoid |
| B31 | Fuel temperature sensor |
| F | Fuse |
| X28-I | Fuse box/relay plate, engine bay |
| R5 | Glow plug |
| A104 | Glow plug control module |
| K76 | Ignition auxiliary circuits relay |
| K79 | Ignition main circuits relay |
| 15 | Ignition switch - ignition ON |
| A162 | Immobilizer control module |
| B178 | Injection pump position sensor |
| B25 | Intake air temperature (IAT) sensor |
| B83 | Manifold absolute pressure (MAP) sensor |
| B30 | Mass air flow (MAF) sensor |
| A11 | Multifunction control module |
| A81 | Power steering control module |
| Y68 | Turbocharger (TC) wastegate regulating valve |
| VAN | Vehicle area network (data bus) |
| A123 | Vehicle speed sensor (VSS) signal amplifier |
| B19 | Wheel speed sensor, left front |