

D

**B**

A

25	23	21	19	17	15	13	11	9	7	5	3	1
26	24	22	20	18	16	14	12	10	8	6	4	2

K143	AC compressor clutch relay
G1	Alternator
B121	Barometric pressure (BARO) sensor
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A166	Distributor
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B75	Engine speed (RPM) sensor
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
B149	Exhaust gas recirculation (EGR) valve position sensor
M12	Fuel pump
F	Fuse
B72	Heated oxygen sensor (HO2S)
S17	Heater/AC motor switch
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
S39	Inertia fuel shut-off (IFS) switch - UK
Y3	Injector
R41	Injector series resistor
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
Y84	Intake air valve control valve
Y102	Intake manifold air control solenoid
B83	Manifold absolute pressure (MAP) sensor
S259	Park/neutral position (PNP) switch
K46	Relay module
P7	Tachometer
X87	Tachometer diagnostic link
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
H27	Transmission shift warning lamp/s
B33	Vehicle speed sensor (VSS)