

30058

□19 □18 □17 □16 □15 □14 □13 □12 □11 □10 □9 □8 □7 □6 □5 □4 □3 □2 □1  
□37 □36 □35 □34 □33 □32 □31 □30 □29 □28 □27 □26 □25 □24 □23 □22 □21 □20  
□55 □54 □53 □52 □51 □50 □49 □48 □47 □46 □45 □44 □43 □42 □41 □40 □39 □38

A16	ABS control module	<b>X20XEV Vectra B (1995-2000)</b>
K143	AC compressor clutch relay	
S63	AC refrigerant pressure switch	
31	Battery -	
30	Battery +	
B132	Camshaft position (CMP) sensor	
B54	Crankshaft position (CKP) sensor	
X1	Data link connector (DLC)	
A161	Digital multifunction display	
Y28	EGR system valve	
A35	Engine control module (ECM)	
K46	Engine control relay	
B24	Engine coolant temperature (ECT) sensor	
H63	Engine malfunction indicator lamp (MIL)	
B75	Engine speed (RPM) sensor	
Y104	Evaporative emission (EVAP) canister purge valve	
M12	Fuel pump	
K20	Fuel pump relay	
F	Fuse	
B72	Heated oxygen sensor (HO2S)	
Y99	Idle air control (IAC) valve	
A52	Ignition amplifier	
T1	Ignition coil	
15	Ignition switch - ignition ON	
50	Ignition switch - start signal	
Y3	Injector	
A5	Instrument panel	
B25	Intake air temperature (IAT) sensor	
Y102	Intake manifold air control solenoid	
B69	Knock sensor (KS)	
B30	Mass air flow (MAF) sensor	
M73	Secondary air injection (AIR) pump motor	
K152	Secondary air injection (AIR) pump relay	
Y111	Secondary air injection (AIR) solenoid	
B147	Throttle position (TP) sensor	
A57	Transmission control module (TCM)	