



A16	ABS control module
K143	AC compressor clutch relay
A63	AC control module
S63	AC refrigerant pressure switch
31	Battery -
30	Battery +
Y81	Camshaft position (CMP) actuator
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
B75	Engine speed (RPM) sensor
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
K94	Heated oxygen sensor (HO2S) relay
Y99	Idle air control (IAC) valve
T1	Ignition coil
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
S249	Transmission shift position switch
A19	Trip computer



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the

harness connector.



30041