



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	

X88	AC connector
31	Battery -
30	Battery +
R62	CO adjustment resistor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
Y3	Injector
B25	Intake air temperature (IAT) sensor
W21	Octane coding plug
K46	Relay module
S104	Throttle position (TP) switch
A57	Transmission control module (TCM)
B33	Vehicle speed sensor (VSS)
B148	Volume air flow (VAF) sensor