



| | |
|------|--|
| S338 | AC refrigerant dual pressure switch |
| G1 | Alternator |
| 31 | Battery - |
| 30 | Battery + |
| B132 | Camshaft position (CMP) sensor |
| B54 | Crankshaft position (CKP) sensor |
| X1 | Data link connector (DLC) |
| A6 | Digital clock |
| K46 | Engine control (EC) relay |
| A35 | Engine control module (ECM) |
| K12 | Engine coolant blower motor relay |
| B24 | Engine coolant temperature (ECT) sensor |
| Y104 | Evaporative emission (EVAP) canister purge valve |
| M12 | Fuel pump (FP) |
| K20 | Fuel pump (FP) relay |
| F | Fuse |
| B72 | Heated oxygen sensor (HO2S) |
| Y56 | Idle speed control (ISC) actuator |
| K76 | Ignition auxiliary circuits relay |
| T1 | Ignition coil |
| 15 | Ignition switch - ignition ON |
| 50 | Ignition switch - start signal |
| A162 | Immobilizer control module |
| S39 | Inertia fuel shut-off (IFS) switch |
| Y3 | Injector |
| A5 | Instrument panel |
| B25 | Intake air temperature (IAT) sensor |
| B83 | Manifold absolute pressure (MAP) sensor |
| S231 | Power steering pressure (PSP) switch |
| M1 | Starter motor |
| K4 | Starter motor relay |
| B147 | Throttle position (TP) sensor |
| S249 | Transmission range (TR) switch |
| B33 | Vehicle speed sensor (VSS) |