



K143	AC compressor clutch relay
S63	AC refrigerant pressure switch
G1	Alternator
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
Y28	EGR system valve
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
Y133	Engine mounting control solenoid
B75	Engine speed (RPM) sensor
Y104	Evaporative emission (EVAP) canister purge valve
B149	Exhaust gas recirculation (EGR) valve position sensor
M12	Fuel pump
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
A162	Immobilizer control module
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
K46	Relay module
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
B33	Vehicle speed sensor (VSS)

