



36861





A16	ABS control module
K143	AC compressor clutch relay
S63	AC refrigerant pressure switch
S341	AC refrigerant triple pressure switch
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
S79	Cruise control master switch
X1	Data link connector (DLC)
A161	Digital multifunction display
K46	Engine control (EC) relay
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
H5	Engine oil pressure warning lamp
S25	Engine oil pressure warning lamp switch
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
B149	Exhaust gas recirculation (EGR) valve position sensor
P3	Fuel gauge
M12	Fuel pump (FP)
K20	Fuel pump (FP) relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
T1	Ignition coil
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
H50	Service indicator
P7	Tachometer
A177	Throttle control unit
M89	Throttle motor
B169	Throttle motor position sensor
A61	Traction control module