

1	Crankshaft position (CKP) sensor
2	Data link connector (DLC) - under RH fascia
3	Engine control module (ECM)
4	Engine coolant temperature (ECT) sensor
5	Evaporative emission (EVAP) canister purge valve
6	Fuel filter - underside rear
7	Fuel pressure regulator
8	Fuel pump - in tank
9	Heated oxygen sensor (HO2S) - exhaust front
10	Idle air control (IAC) valve
11	Ignition amplifier - in ECM
12	Ignition coil
13	Inertia fuel shut-off (IFS) switch
14	Injectors
15	Intake air temperature (IAT) sensor
16	Knock sensor (KS)
17	Manifold absolute pressure (MAP) sensor
18	Power steering pressure (PSP) switch
19	Relay module
20	Throttle body heater
21	Throttle position (TP) sensor
22	Vehicle speed sensor (VSS) - transmission

