



X88	AC connection
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
S79	Cruise control master switch
X1	Data link connector (DLC)
A161	Digital multifunction display
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
B156	Engine oil temperature sensor
Y28	Exhaust gas recirculation (EGR) solenoid
R64	Fuel filter heater
K138	Fuel heater relay
A150	Fuel injection pump
A107	Fuel injection pump control module
Y132	Fuel injection timing solenoid
Y159	Fuel quantity adjuster
B31	Fuel temperature sensor
F	Fuse
R5	Glow plug
A104	Glow plug control module
H25	Glow plug warning lamp
15	Ignition switch - ignition ON
A162	Immobilizer control module
B25	Intake air temperature (IAT) sensor
Y102	Intake manifold air control solenoid
H63	Malfunction indicator lamp (MIL)
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
P7	Tachometer
Y68	Turbocharger (TC) wastegate regulating valve