





| | |
|---------|---|
| A16 | ABS control module |
| K143 | AC compressor clutch relay |
| B161 | AC refrigerant pressure sensor |
| B138 | Accelerator pedal position (APP) sensor |
| 31 | Battery - |
| 30 | Battery + |
| S13 | Brake pedal position (BPP) switch |
| B132 | Camshaft position (CMP) sensor |
| S258 | Clutch pedal position (CPP) switch |
| CAN | Controller area network (data bus) |
| B54 | Crankshaft position (CKP) sensor |
| X1 | Data link connector (DLC) |
| K46 | Engine control (EC) relay |
| A35 | Engine control module (ECM) |
| K12-I | Engine coolant blower motor relay 1 |
| K12-II | Engine coolant blower motor relay 2 |
| K12-III | Engine coolant blower motor relay 3 |
| K12-IV | Engine coolant blower motor relay 4 |
| P4 | Engine coolant temperature (ECT) gauge |
| B24 | Engine coolant temperature (ECT) sensor |
| H63 | Engine malfunction indicator lamp (MIL) |
| B86 | Engine oil level sensor |
| S25 | Engine oil pressure warning lamp switch |
| Y104 | Evaporative emission (EVAP) canister purge valve |
| Y151 | Exhaust gas recirculation (EGR) valve actuator |
| B149 | Exhaust gas recirculation (EGR) valve position sensor |
| P3 | Fuel gauge |
| B3 | Fuel gauge tank sensor |
| M12 | Fuel pump (FP) |
| K20 | Fuel pump (FP) relay |
| F | Fuse |
| X28-I | Fuse box/relay plate, engine bay |
| B72-II | Heated oxygen sensor (HO2S) - after cat |
| B72-I | Heated oxygen sensor (HO2S) - before cat |
| T1 | Ignition coil |
| K79 | Ignition main circuits relay |
| 15 | Ignition switch - ignition ON |
| A162 | Immobilizer control module |
| Y3 | Injector |
| A5 | Instrument panel |
| B25 | Intake air temperature (IAT) sensor |
| B69 | Knock sensor (KS) |

| | |
|------|---|
| B30 | Mass air flow (MAF) sensor |
| A11 | Multifunction control module |
| A81 | Power steering control module |
| H50 | Service indicator |
| P7 | Tachometer |
| A177 | Throttle control unit |
| M89 | Throttle motor |
| B169 | Throttle motor position sensor |
| VAN | Vehicle area network (data bus) |
| A123 | Vehicle speed sensor (VSS) signal amplifier |
| B19 | Wheel speed sensor, left front |

