





| | |
|------|---|
| A16 | ABS control module |
| K143 | AC compressor clutch relay |
| S63 | AC refrigerant pressure switch |
| S341 | AC refrigerant triple pressure switch |
| B138 | Accelerator pedal position (APP) sensor |
| 31 | Battery - |
| 30 | Battery + |
| S13 | Brake pedal position (BPP) switch |
| B132 | Camshaft position (CMP) sensor |
| S258 | Clutch pedal position (CPP) switch |
| B54 | Crankshaft position (CKP) sensor |
| S79 | Cruise control master switch |
| X1 | Data link connector (DLC) |
| A161 | Digital multifunction display |
| K46 | Engine control (EC) relay |
| A35 | Engine control module (ECM) |
| B24 | Engine coolant temperature (ECT) sensor |
| H63 | Engine malfunction indicator lamp (MIL) |
| H5 | Engine oil pressure warning lamp |
| S25 | Engine oil pressure warning lamp switch |
| Y104 | Evaporative emission (EVAP) canister purge valve |
| Y28 | Exhaust gas recirculation (EGR) solenoid |
| B149 | Exhaust gas recirculation (EGR) valve position sensor |
| P3 | Fuel gauge |
| M12 | Fuel pump (FP) |
| K20 | Fuel pump (FP) relay |
| F | Fuse |
| B72 | Heated oxygen sensor (HO2S) |
| T1 | Ignition coil |
| 15 | Ignition switch - ignition ON |
| A162 | Immobilizer control module |
| Y3 | Injector |
| A5 | Instrument panel |
| B25 | Intake air temperature (IAT) sensor |
| B69 | Knock sensor (KS) |
| B30 | Mass air flow (MAF) sensor |
| H50 | Service indicator |
| P7 | Tachometer |
| A177 | Throttle control unit |
| M89 | Throttle motor |
| B169 | Throttle motor position sensor |
| A61 | Traction control module |