

X88	AC connector
B121	Barometric pressure (BARO) sensor
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
S57	Closed throttle position (CTP) switch
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) valve
M12	Fuel pump
X63	Fuel pump diagnostic link
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
S231	Power steering pressure (PSP) switch
K46	Relay module - Carisma 1996-97
X87	Tachometer diagnostic link
B147	Throttle position (TP) sensor
B33	Vehicle speed sensor (VSS)
B148	Volume air flow (VAF) sensor