



A16	ABS control module
K143	AC compressor clutch relay
S63	AC refrigerant pressure switch
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A161	Digital multifunction display
Y28	EGR system valve
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B75	Engine speed (RPM) sensor
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
Y102	Intake manifold air control solenoid
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
M73	Secondary air injection (AIR) pump motor
K152	Secondary air injection (AIR) pump relay
Y111	Secondary air injection (AIR) solenoid
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)