



31	Battery -
30	Battery +
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A161	Digital multifunction display - Astra-F
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
A147	Exhaust gas recirculation (EGR) amplifier
Y28	Exhaust gas recirculation (EGR) solenoid
B149	Exhaust gas recirculation (EGR) valve position sensor
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal - Astra-F - AT
Y3	Injector
A5	Instrument panel - MIL light
A152	Knock control module
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
B72	Oxygen sensor (O2S)
P7	Tachometer
B147	Throttle position (TP) sensor
X79	Transmission connector - Astra-F
B33	Vehicle speed sensor (VSS)