


□1 □2 □3 □4 □5 □6 □7 □8 □9 □10 □11 □12 □13 □14 □15 □16 □17 □18 □19  
□20 □21 □22 □23 □24 □25 □26 □27 □28 □29 □30 □31 □32 □33 □34 □35 □36 □37  
□38 □39 □40 □41 □42 □43 □44 □45 □46 □47 □48 □49 □50 □51 □52 □53 □54 □55



X88	AC connector
A16	Anti-lock braking system (ABS) control module
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A161	Digital multifunction display
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
B149	Exhaust gas recirculation (EGR) valve position sensor
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
T1	Ignition coil
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel - MIL light
B25	Intake air temperature (IAT) sensor
Y102	Intake manifold air control solenoid
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
M73	Secondary air injection (AIR) pump
K152	Secondary air injection (AIR) pump relay
Y111	Secondary air injection (AIR) solenoid
P7	Tachometer
B147	Throttle position (TP) sensor
X79	Transmission connector