

|        |   |
|--------|---|
| A16    | ABS control module                                |
| B161   | AC refrigerant pressure sensor                    |
| 31     | Battery -   |
| 30     | Battery +   |
| CAN-H  | Controller area network (data bus) high           |
| CAN-L  | Controller area network (data bus) low            |
| B54    | Crankshaft position (CKP) sensor                  |
| X1     | Data link connector (DLC)                         |
| A207   | Electronic stability program (ESP) control module |
| A35    | Engine control module (ECM)                       |
| M6     | Engine coolant blower motor                       |
| K12    | Engine coolant blower motor relay                 |
| K12-I  | Engine coolant blower motor relay 1               |
| K12-II | Engine coolant blower motor relay 2               |
| R46    | Engine coolant blower motor resistor              |
| R46-I  | Engine coolant blower motor resistor 1            |
| R46-II | Engine coolant blower motor resistor 2            |
| B24    | Engine coolant temperature (ECT) sensor           |
| H63    | Engine malfunction indicator lamp (MIL)           |
| Y28    | Exhaust gas recirculation (EGR) solenoid          |
| B171   | Fuel lever position sensor                        |
| Y12    | Fuel shut-off solenoid                            |
| F      | Fuse  |
| X28-II | Fuse box/relay plate, engine bay                  |
| X28-I  | Fuse box/relay plate, fascia                      |
| K93    | Glow plug timer relay                             |
| H25    | Glow plug warning lamp                            |
| R5     | Glow plugs  |
| 15     | Ignition switch - ignition ON                     |
| Y131   | Injection pump advance solenoid                   |
| A150   | Injection pump assembly                           |
| B141   | Injector needle lift sensor                       |
| A5     | Instrument panel                                  |
| A75    | Instrumentation control module                    |
| Y66    | Intake air flap control actuator                  |
| B25    | Intake air temperature (IAT) sensor               |
| B30    | Mass air flow (MAF) sensor                        |
| A11-I  | Multifunction control module 1                    |
| A11-II | Multifunction control module 2                    |
| VAN    | Vehicle area network                              |
| B33    | Vehicle speed sensor (VSS)                        |

|                   |                  |                          |              |
|-------------------|------------------|--------------------------|--------------|
| bl = blue         | br = brown       | el = cream               | ge = yellow  |
| gn = green        | gr = grey        | nf = neutral             | og = orange  |
| rs = pink         | rt = red         | sw = black               | vi = violet  |
| ws = white        | hbl = light blue | hgn = light green        | rbr = maroon |
| x = braided cable | y = high tension | z = non-cable connection |              |

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

