



S51	AC evaporator temperature switch
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A161	Digital multifunction display
A35	Engine control module (ECM)
A95	Engine coolant blower motor control module
K12	Engine coolant blower motor relay
B24	Engine coolant temperature (ECT) sensor
P4	Engine coolant temperature gauge
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
B149	Exhaust gas recirculation (EGR) valve position sensor
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
T1	Ignition coil
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
P7	Tachometer
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
B33	Vehicle speed sensor (VSS)
X91	Vehicle speed sensor (VSS) connector