





A16	ABS control module - if fitted
A63	AC control module - if fitted
S149	AC master switch
B138	Accelerator pedal position (APP) sensor
B121	Barometric pressure (BARO) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
S80	Cruise control selector switch
X1	Data link connector (DLC)
A161	Digital multifunction display
K46	Engine control (EC) relay
A35	Engine control module (ECM)
A95	Engine coolant blower motor control module
K12	Engine coolant blower motor relay
B24	Engine coolant temperature (ECT) sensor
S389	Engine oil pressure switch
Y28	Exhaust gas recirculation (EGR) solenoid
R64	Fuel filter heater
K138	Fuel heater relay
A150	Fuel injection pump
A107	Fuel injection pump control module
Y132	Fuel injection timing solenoid
Y159	Fuel quantity adjuster
K280	Fuel quantity adjuster relay
B31	Fuel temperature sensor
F	Fuse
R5	Glow plug
A104	Glow plug control module
15	Ignition switch - ignition ON
A162	Immobilizer control module
B178	Injection pump position sensor
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
Y68	Turbocharger (TC) wastegate regulating valve
B33	Vehicle speed sensor (VSS)