

The diagram shows a 10x10 grid of circles. The grid is divided into two sections, A and B, by a vertical line. Section A contains numbers 1-10 in the first row, 11-20 in the second row, 21-30 in the third row, and 31-38 in the fourth row. Section B contains numbers 1-10 in the first row, 11-20 in the second row, 21-30 in the third row, and 31-38 in the fourth row.

K143	AC compressor clutch relay
S63	AC refrigerant pressure switch
S341	AC refrigerant triple pressure switch
31	Battery -
30	Battery +
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
B149	Exhaust gas recirculation (EGR) valve position sensor
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
P7	Tachometer
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
P9	Vehicle speedometer