



30365

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |   |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|
| 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9  | 8  | 7  | 6  | 5  | 4  | 3  | 2  | 1 |
| 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 |   |
| 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | 38 |   |

|      |  |                              |
|------|--|------------------------------|
| K143 | AC compressor clutch relay                       | <b>X20XEV Vectra A (-95)</b> |
| X88  | AC connector                                     |                              |
| S63  | AC refrigerant pressure switch                   |                              |
| S341 | AC refrigerant triple pressure switch            |                              |
| A16  | Anti-lock braking system (ABS) control module    |                              |
| 31   | Battery -  |                              |
| 30   | Battery +  |                              |
| B132 | Camshaft position (CMP) sensor                   |                              |
| B54  | Crankshaft position (CKP) sensor                 |                              |
| X1   | Data link connector (DLC)                        |                              |
| A161 | Digital multifunction display                    |                              |
| A35  | Engine control module (ECM)                      |                              |
| K46  | Engine control relay                             |                              |
| B24  | Engine coolant temperature (ECT) sensor          |                              |
| H63  | Engine malfunction indicator lamp (MIL)          |                              |
| B75  | Engine speed (RPM) sensor                        |                              |
| Y104 | Evaporative emission (EVAP) canister purge valve |                              |
| Y28  | Exhaust gas recirculation (EGR) solenoid         |                              |
| M12  | Fuel pump  |                              |
| K20  | Fuel pump relay                                  |                              |
| F    | Fuse   |                              |
| B72  | Heated oxygen sensor (HO2S)                      |                              |
| Y99  | Idle air control (IAC) valve                     |                              |
| T1   | Ignition coil                                    |                              |
| 15   | Ignition switch - ignition ON                    |                              |
| 50   | Ignition switch - start signal                   |                              |
| Y3   | Injector   |                              |
| A5   | Instrument panel - MIL light                     |                              |
| B25  | Intake air temperature (IAT) sensor              |                              |
| B69  | Knock sensor (KS)                                |                              |
| B30  | Mass air flow (MAF) sensor                       |                              |
| S328 | Module temperature switch                        |                              |
| A171 | Relay module                                     |                              |
| K213 | Reverse polarity protection relay                |                              |
| M73  | Secondary air injection (AIR) pump               |                              |
| K152 | Secondary air injection (AIR) pump relay         |                              |
| Y111 | Secondary air injection (AIR) solenoid           |                              |
| K4   | Starter motor relay                              |                              |
| P7   | Tachometer                                       |                              |
| B147 | Throttle position (TP) sensor                    |                              |
| X79  | Transmission connector                           |                              |
| A57  | Transmission control module (TCM)                |                              |
| B33  | Vehicle speed sensor (VSS)                       |                              |