



A16	ABS control module
K143	AC compressor clutch relay
B161	AC refrigerant pressure sensor
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN	Controller area network (data bus)
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A161	Digital multifunction display
K46	Engine control (EC) relay
A35	Engine control module (ECM)
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
K12-IV	Engine coolant blower motor relay 4
P4	Engine coolant temperature (ECT) gauge
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B86	Engine oil level sensor
S389	Engine oil pressure switch
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
B149	Exhaust gas recirculation (EGR) valve position sensor
P3	Fuel gauge
M12	Fuel pump (FP)
K20	Fuel pump (FP) relay
F	Fuse
X28-I	Fuse box/relay plate, engine bay
B72-II	Heated oxygen sensor (HO2S) - after cat
B72-I	Heated oxygen sensor (HO2S) - before cat
T1	Ignition coil
K79	Ignition main circuits relay
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor