


| | |
|---------|--|
| A16 | ABS control module |
| K143 | AC compressor clutch relay |
| B138 | Accelerator pedal position (APP) sensor |
| X93 | Airbag spiral cable |
| G1 | Alternator |
| H1 | Alternator warning lamp |
| C3 | Audio unit suppressor |
| 31 | Battery - |
| 30 | Battery + |
| S13 | Brake pedal position (BPP) switch |
| Y189 | Brake system vacuum solenoid |
| Y81 | Camshaft position (CMP) actuator |
| B132 | Camshaft position (CMP) sensor |
| B132-I | Camshaft position (CMP) sensor 1 |
| B132-II | Camshaft position (CMP) sensor 2 |
| S258 | Clutch pedal position (CPP) switch |
| CAN-H | Controller area network (data bus) high |
| CAN-L | Controller area network (data bus) low |
| B54 | Crankshaft position (CKP) sensor |
| X1 | Data link connector (DLC) |
| X1-I | Data link connector (DLC) 1 |
| K46 | Engine control (EC) relay |
| A35 | Engine control module (ECM) |
| M6 | Engine coolant blower motor |
| B187 | Engine coolant blower motor temperature sensor |
| B24 | Engine coolant temperature (ECT) sensor |
| B86 | Engine oil level sensor |
| H37 | Engine oil level warning lamp |
| H5 | Engine oil pressure warning lamp |
| S25 | Engine oil pressure warning lamp switch |
| Y104 | Evaporative emission (EVAP) canister purge valve |
| B131 | Exhaust gas temperature sensor |
| M12 | Fuel pump |
| K20 | Fuel pump relay |
| F | Fuse |
| X28-II | Fuse box/relay plate, engine bay |
| X28-I | Fuse box/relay plate, fascia |
| S3 | Headlamp switch |
| B72 | Heated oxygen sensor (HO2S) |
| B72-I | Heated oxygen sensor (HO2S) 1 |
| B72-II | Heated oxygen sensor (HO2S) 2 |
| B72-III | Heated oxygen sensor (HO2S) 3 |
| B72-IV | Heated oxygen sensor (HO2S) 4 |
| Y99 | Idle air control (IAC) valve |
| T1 | Ignition coil |
| S1 | Ignition switch |
| 15 | Ignition switch - ignition ON |
| 50 | Ignition switch - start signal |
| A162 | Immobilizer control module |
| Y3 | Injector |
| K251 | Injector relay |
| A5 | Instrument panel |

| | |
|---------|--|
| A75 | Instrumentation control module |
| B69 | Knock sensor (KS) |
| B69-I | Knock sensor (KS) 1 |
| B69-II | Knock sensor (KS) 2 |
| B69-III | Knock sensor (KS) 3 |
| B30 | Mass air flow (MAF) sensor |
| M86 | Module cooling fan |
| A193 | Multi switch assembly |
| S259 | Neutral position (NP) switch |
| M73 | Secondary air injection (AIR) pump |
| K152 | Secondary air injection (AIR) pump relay |
| W11 | Spare cable |
| M1 | Starter motor |
| S365 | Steering wheel multifunction switch |
| S365-II | Steering wheel multifunction switch 2 |
| M89 | Throttle motor |
| B169 | Throttle motor position sensor |
| B147 | Throttle position (TP) sensor |
| A57 | Transmission control module (TCM) |
| 15 | Under front seat, LH |



| | | | |
|-------------------|------------------|--------------------------|--------------|
| bl = blue | br = brown | el = cream | ge = yellow |
| gn = green | gr = grey | nf = neutral | og = orange |
| rs = pink | rt = red | sw = black | vi = violet |
| ws = white | hbl = light blue | hgn = light green | rbr = maroon |
| x = braided cable | y = high tension | z = non-cable connection | |

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

