



30373

19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21	20	
55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40	39	38	

X88	AC connector
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
X1	Data link connector (DLC)
A161	Digital multifunction display
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B75	Engine speed (RPM) sensor
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
M12	Fuel pump
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel - MIL light
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
W21	Octane adjuster
K46	Relay module
P7	Tachometer
B147	Throttle position (TP) sensor
A61	Traction control module
X79	Transmission connector
A57	Transmission control module (TCM)
B33	Vehicle speed sensor (VSS)