

| | | | | | | | | | | | | | | | | | |
|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| <u>1</u> | <u>2</u> | <u>3</u> | <u>4</u> | <u>5</u> | <u>6</u> | <u>7</u> | <u>8</u> | <u>9</u> | <u>10</u> | <u>11</u> | <u>12</u> | <u>13</u> | <u>14</u> | <u>15</u> | <u>16</u> | <u>17</u> | <u>18</u> |
| <u>19</u> | <u>20</u> | <u>21</u> | <u>22</u> | <u>23</u> | <u>24</u> | <u>25</u> | <u>26</u> | <u>27</u> | <u>28</u> | <u>29</u> | <u>30</u> | <u>31</u> | <u>32</u> | <u>33</u> | <u>34</u> | <u>35</u> | |

| | |
|------|--|
| X88 | AC connector |
| 31 | Battery - |
| 30 | Battery + |
| R62 | CO adjustment resistor |
| B54 | Crankshaft position (CKP) sensor |
| X1 | Data link connector (DLC) |
| A35 | Engine control module (ECM) |
| B24 | Engine coolant temperature (ECT) sensor |
| H63 | Engine malfunction indicator lamp (MIL) |
| Y104 | Evaporative emission (EVAP) canister purge valve |
| M12 | Fuel pump |
| F | Fuse |
| B72 | Heated oxygen sensor (HO2S) |
| Y99 | Idle air control (IAC) valve |
| A52 | Ignition amplifier |
| T1 | Ignition coil |
| 15 | Ignition switch - ignition ON |
| 50 | Ignition switch - start signal |
| Y3 | Injector |
| B25 | Intake air temperature (IAT) sensor |
| W21 | Octane coding plug |
| K46 | Relay module |
| S104 | Throttle position (TP) switch |
| A57 | Transmission control module (TCM) |
| B33 | Vehicle speed sensor (VSS) |
| B148 | Volume air flow (VAF) sensor |