



19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21	20	
55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40	39	38	

X88	AC connector
A16	Anti-lock braking system (ABS) control module
31	Battery -
30	Battery +
X1	Data link connector (DLC)
A161	Digital multifunction display
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
B75	Engine speed (RPM) sensor
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
T1	Ignition coil
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel - MIL light
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)