



C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12	C13	C14	C15	C16
D1	D2	D3	D4	D5	D6	D7	D8	D9	D10	D11	D12	D13	D14	D15	D16

A1	A2	A3	A4	A5	A6	A7	A8	A9	A10	A11	A12	A13	A14	A15	A16
B1	B2	B3	B4	B5	B6	B7	B8	B9	B10	B11	B12	B13	B14	B15	B16

K143	AC compressor clutch relay
S63	AC refrigerant pressure switch
31	Battery -
30	Battery +
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A161	Digital multifunction display
Y28	EGR system valve
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
F	Fuse
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
B72	Oxygen sensor (O2S)
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
B33	Vehicle speed sensor (VSS)

