


|         |   |
|---------|---|
| A16     | ABS control module                                    |
| B161    | AC refrigerant pressure sensor                        |
| B138    | Accelerator pedal position (APP) sensor               |
| G1      | Alternator  |
| 31      | Battery -   |
| 30      | Battery +   |
| S13     | Brake pedal position (BPP) switch                     |
| B132    | Camshaft position (CMP) sensor                        |
| S258    | Clutch pedal position (CPP) switch                    |
| CAN-H   | Controller area network (data bus) high               |
| CAN-L   | Controller area network (data bus) low                |
| B54     | Crankshaft position (CKP) sensor                      |
| X1      | Data link connector (DLC)                             |
| A207    | Electronic stability program (ESP) control module     |
| A35     | Engine control module (ECM)                           |
| M6      | Engine coolant blower motor                           |
| K12     | Engine coolant blower motor relay                     |
| K12-I   | Engine coolant blower motor relay 1                   |
| K12-II  | Engine coolant blower motor relay 2                   |
| R46     | Engine coolant blower motor resistor                  |
| B24     | Engine coolant temperature (ECT) sensor               |
| H63     | Engine malfunction indicator lamp (MIL)               |
| Y104    | Evaporative emission (EVAP) canister purge valve      |
| Y28     | Exhaust gas recirculation (EGR) solenoid              |
| B149    | Exhaust gas recirculation (EGR) valve position sensor |
| M12     | Fuel pump   |
| F       | Fuse  |
| X28-II  | Fuse box/relay plate - engine bay 1                   |
| X28-III | Fuse box/relay plate - engine bay 2                   |
| X28-I   | Fuse box/relay plate - fascia 1                       |
| B72-I   | Heated oxygen sensor (HO2S) 1                         |
| B72-II  | Heated oxygen sensor (HO2S) 2                         |
| T1      | Ignition coil   |
| S1      | Ignition switch                                       |
| 15      | Ignition switch - ignition ON                         |
| Y3      | Injector  |
| A5      | Instrument panel                                      |
| A75     | Instrumentation control module                        |
| B25     | Intake air temperature (IAT) sensor                   |
| B69     | Knock sensor (KS)                                     |
| B83     | Manifold absolute pressure (MAP) sensor               |
| A11-I   | Multifunction control module 1                        |
| A11-II  | Multifunction control module 2                        |
| M73     | Secondary air injection (AIR) pump                    |
| P7      | Tachometer  |
| R10     | Throttle body heater                                  |
| M89     | Throttle motor  |
| B169    | Throttle motor position sensor                        |
| VAN     | Vehicle area network                                  |
| P9      | Vehicle speedometer                                   |



|                   |                  |                          |              |
|-------------------|------------------|--------------------------|--------------|
| bl = blue         | br = brown       | el = cream               | ge = yellow  |
| gn = green        | gr = grey        | nf = neutral             | og = orange  |
| rs = pink         | rt = red         | sw = black               | vi = violet  |
| ws = white        | hbl = light blue | hgn = light green        | rbr = maroon |
| x = braided cable | y = high tension | z = non-cable connection |              |

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.



