



30364

K143	AC compressor clutch relay
X88	AC connector
S63	AC refrigerant pressure switch
S341	AC refrigerant triple pressure switch
A16	Anti-lock braking system (ABS) control module
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A161	Digital multifunction display
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B75	Engine speed (RPM) sensor
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
Y3	Injector
A5	Instrument panel - MIL light
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
S328	Module temperature switch
A171	Relay module
K213	Reverse polarity protection relay
M73	Secondary air injection (AIR) pump
K152	Secondary air injection (AIR) pump relay
Y111	Secondary air injection (AIR) solenoid
K4	Starter motor relay
P7	Tachometer
B147	Throttle position (TP) sensor
X79	Transmission connector
A57	Transmission control module (TCM)
B33	Vehicle speed sensor (VSS)