



| | |
|------|--|
| A16 | ABS control module |
| B22 | ABS wheel speed sensor, right rear |
| K143 | AC compressor clutch relay |
| B138 | Accelerator pedal position (APP) sensor |
| 31 | Battery - |
| 30 | Battery + |
| S13 | Brake pedal position (BPP) switch |
| Y81 | Camshaft position (CMP) actuator |
| B132 | Camshaft position (CMP) sensor |
| S258 | Clutch pedal position (CPP) switch |
| B54 | Crankshaft position (CKP) sensor |
| X1 | Data link connector (DLC) |
| A35 | Engine control module (ECM) |
| K46 | Engine control relay |
| M6 | Engine coolant blower motor |
| B187 | Engine coolant blower motor temperature sensor |
| B24 | Engine coolant temperature (ECT) sensor |
| R96 | Engine coolant thermostat |
| B156 | Engine oil temperature sensor |
| Y104 | Evaporative emission (EVAP) canister purge valve |
| Y141 | Exhaust gas control solenoid |
| M12 | Fuel pump |
| K20 | Fuel pump relay |
| F | Fuse |
| S3 | Headlamp switch |
| B72 | Heated oxygen sensor (HO2S) |
| Y99 | Idle air control (IAC) valve |
| T1 | Ignition coil |
| S1 | Ignition switch |
| 15 | Ignition switch - ignition ON |
| A162 | Immobilizer control module |
| Y3 | Injector |
| K251 | Injector relay |
| A5 | Instrument panel |
| B25 | Intake air temperature (IAT) sensor |
| Y102 | Intake manifold air control solenoid |
| B69 | Knock sensor (KS) |
| B30 | Mass air flow (MAF) sensor |
| M73 | Secondary air injection (AIR) pump |
| K152 | Secondary air injection (AIR) pump relay |
| Y111 | Secondary air injection (AIR) solenoid |
| S365 | Steering wheel multifunction switch |
| M89 | Throttle position motor |
| A61 | Traction control module |
| A57 | Transmission control module (TCM) |
| 15 | Under LH front seat, under carpet |

A



B



J.D109092

| | | | |
|-------------------|------------------|--------------------------|--------------|
| bl = blue | br = brown | el = cream | ge = yellow |
| gn = green | gr = grey | nf = neutral | og = orange |
| rs = pink | rt = red | sw = black | vi = violet |
| ws = white | hbl = light blue | hgn = light green | rbr = maroon |
| x = braided cable | y = high tension | z = non-cable connection | |

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

