

□19 □18 □17 □16 □15 □14 □13 □12 □11 □10 □9 □8 □7 □6 □5 □4 □3 □2 □1  
□37 □36 □35 □34 □33 □32 □31 □30 □29 □28 □27 □26 □25 □24 □23 □22 □21 □20  
□55 □54 □53 □52 □51 □50 □49 □48 □47 □46 □45 □44 □43 □42 □41 □40 □39 □38

X88	AC connector
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B75	Engine speed (RPM) sensor
Y104	Evaporative emission (EVAP) canister purge valve
S327	First gear position switch
Y63	Fuel pressure regulator control solenoid
M12	Fuel pump
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
K46	Relay module
S28	Reverse gear position switch
P7	Tachometer
B147	Throttle position (TP) sensor
A19	Trip computer
Y68	Turbocharger wastegate regulating valve
B33	Vehicle speed sensor (VSS)