

X88	AC connector
G1	Alternator
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
Y28	EGR system valve
B149	EGR valve position sensor
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B75	Engine speed (RPM) sensor
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
R41	Injector series resistor
A5	Instrument panel - MIL light
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
X87	Tachometer diagnostic link
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
B33	Vehicle speed sensor (VSS)