



X88	AC connector
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
R62	CO adjustment resistor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A166	Distributor
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
Y3	Injector
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
W21	Octane coding plug
K46	Relay module
P7	Tachometer
S104	Throttle position (TP) switch
A61	Traction control module
A19	Trip computer
B33	Vehicle speed sensor (VSS)