



C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12	C13	C14	C15	C16
D1	D2	D3	D4	D5	D6	D7	D8	D9	D10	D11	D12	D13	D14	D15	D16

A1	A2	A3	A4	A5	A6	A7	A8	A9	A10	A11	A12
B1	B2	B3	B4	B5	B6	B7	B8	B9	B10	B11	B12

A16	ABS control module
S292	AC/heater function control panel
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A161	Digital multifunction display
A35	Engine control module (ECM)
K12	Engine coolant blower motor relay
B24	Engine coolant temperature (ECT) sensor
P4	Engine coolant temperature gauge
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
B149	Exhaust gas recirculation (EGR) valve position sensor
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
T1	Ignition coil
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
P7	Tachometer
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
B33	Vehicle speed sensor (VSS)