

TRAKTOR PRO

BROWSER

- 1 TREE button
- 2 ROTARY selector
- 3 FAVORITES (REC) button
- 4 LOAD button

DECK

- 5 PLAY/PAUSE button
- 6 CUE button
- 7 SHIFT button
- 8 AUTO LOOP (MOVE GRID) control
- 9 IN (IN ADJUST) button, OUT (OUT ADJUST) button, ACTIVE button
- 10 FUNCTION button
- 11 NEEDLE SEARCH pad
- 12 DECK button
- 13 FILTER control
- 14 FILTER button
- 15 MOVE/HOT CUE selector button
- 16 MOVE panel/HOT CUE panel
- 17 KEY LOCK button
- 18 TEMPO RANGE button
- 19 TEMPO slider
- 20 JOG dial



MIXER

- 21 MAIN VOL control
- 22 HEADPHONES MIX control
- 23 HEADPHONES VOL control
- 24 GAIN control
- 25 EQ (HI, MID, LOW) controls
- 26 EFFECT ASSIGN buttons
- 27 CUE button
- 28 SYNC button
- 29 MASTER button
- 30 CHANNEL fader
- 31 CH FADER START switch

EFFECT

- 32 CROSSFADER
- 33 ADVANCED/CHAINED selector button
- 34 EFFECT button
- 35 DRY/WET control
- 36 SELECT/BACK button
- 37 EFFECT control