

TRAKTOR

Play/Pause **1**

Cue **2**

2nd Function: long press 2 Cue : Cup

Seek (L/R) **3**

POS1, Prev Track / Next Track **4**

Scratch (Vinyl)/Pitch Bend **5**

2nd Function: 3 Seek+ 5 Jog Dial : Fast Seek

Seek **6**

Jog Mode **7**

Tempo **8**

Tempo Reset **9**

Key Lock **10**

Tempo +/-6 +/-10 +/-16 +/-100 **11**

Sync **12**

Master **13**

Monitor On/Off **14**

Hot Cue – 4 **15**

2nd Function: 23 Delete + 15 Hot Cue – 4 : Delete Hot Cue 4

Hot Cue – 3 **16**

2nd Function: 23 Delete + 16 Hot Cue – 3 : Delete Hot Cue 3

Hot Cue – 2 **17**

2nd Function: 23 Delete + 17 Hot Cue – 2 : Delete Hot Cue 2



18 Auto Loop, LOOP/2 (when active)

2nd Function: 14 Monitor On/ Off + 18 Auto Loop : LOOP*2 (when active)

19 Loop In

2nd Function: 2 Cue + 19 Loop In : Loop In Adjust (Cue Mode)

20 Loop Out

2nd Function: 2 Cue + 20 Loop Out : Loop Out Adjust (Cue Mode)

21 Reloop/Exit

22 Flux Mode

23 Prev/Next Cue/Loop

24 Delete Cue/Loop

25 Store Cue/Loop

26 Scroll Tree/List

27 Select/Load

2nd Function: long press 27 Select/ Load : Reassign Deck

28 Back

29 Show Tracks

30 Snap

31 Remaining/Elapsed Time

32 Unload

33 Connect to PC