

## THM 4T80-E FLUID LEAKING FROM BELLHOUSING

**COMPLAINT:** Transaxle fluid leaking from the bell housing area, even after rebuild or a converter seal and torque converter replacement.

**CAUSE:** The cause may be, a transaxle case with a small hairline crack in the shaded area shown in Figure 1, from high line pressure conditions.

**CORRECTION:** Inspect the transaxle case closely in the shaded area shown in Figure 1, for small hairline cracks and replace the transaxle case as necessary. Hydra-matic cast the case thicker in this area during the 1996 model year to eliminate this condition.

### SERVICE INFORMATION:

Transaxle Case Assembly (All Domestic Models) ..... 24210377




Figure 1