



# Technical Service Information

## FORD ATX LOW/REVERSE BRAKE HUB SNAPRING

The ATX low and reverse brake hub snap ring is not used when the transaxle is initially assembled at the plant. When servicing the ATX low and reverse brake hub, technicians may install a snap ring (E7GZ-7D483-8) to aid in assembly of the transaxle, however the snap ring is not required.

