



# Technical Service Information

## THM 4L60 (700-R4) NO 3-4 SHIFT

**COMPLAINT:** No 3-4 shift on any THM 700-R4 transmission.

**CAUSE:** The cause may be that you have installed the 3-4 relay valve in backwards. The 3-4 relay valve is located in front of the 4-3 sequence valve in the valve body (See Figure 1).

**CORRECTION:** Install the 3-4 relay valve correctly (See Figure 1).




Figure 1