



AMI MegaRAC® OpenEdition TiogaPass User Guide

Revision: 0.2

Published by Software R&D



Copyright © 2021 AMI
3095 Satellite Boulevard, Building 800 Suite 425,
Duluth,
Georgia 30096,
U.S.A.
All Rights Reserved


Contents

1. Introduction	3
2. Supported Features in OpenBMC.....	4
2.1. BMC Hardware Component.....	4
2.2. BMC UART Console Access.....	4
2.3. BMC SPI Flash.....	5
2.4. Network Interfaces	5
2.5. LAN Interface.....	5
2.6. KCS Interface	6
2.7. Sideband Interface.....	6
2.8. Sensor Support	6
2.9. System Event Log Support.....	7
2.10. FRU Device Support	8
2.11. BMC Firmware Upgrade Support	9
2.12. WebUI Support.....	14
2.13. KVM Support.....	16
2.14. Reboot BMC.....	17
2.15. Server Power Operation.....	18
2.16. NTP Support.....	19
2.17. BMC Network Settings	20
2.18. User Management Support	21
2.19. IPMI 2.0 and DCMI 1.5 support:	22
2.20. vMedia Support	22
2.21. SSL Certificate Support.....	24
2.22. LDAP Support.....	25
2.23. Redfish Support.....	26
3. BMC Internal Tool Usage.....	28
3.1. GPIO Utilities.....	28
3.2. I2C Tools.....	30
3.3. obmc-console.....	31
3.4. Accessing Devices from U-boot.....	32
4. Supported IPMI Commands	33

1. Introduction

This document describes the supported feature in AMI OpenBMC and how to use the features.

TiogaPass hardware block diagram:




2. Supported Features in OpenBMC

2.1. BMC Hardware Component

Component	Size	Usage
Aspeed AST2500	NA	It's a vastly integrated SOC device playing as a service various functions required for highly manageable serve
DDR4 SDRAM	512MB	BMC memory
SPI flash	32MB	BMC Flash part includes BMC FW, user configuration,
EPROM	8KB	FRU information

2.2. BMC UART Console Access

TiogaPass uses a 14pin V1 debug card header for both BMC and BIOS/Host-OS serial output channel. There is a LCD on the header to display the BIOS POST Code. By default, TiogaPass selects BIOS/Host-OS output channel on the header. User should use the UART Channel selection button on the debug header to change the channel to be connected to BMC debug console.



Please refer to the following table for UART channel and connection


Channel	UART Connection
00	Host console
01	BMC debug console

The settings of the UART ports, for both BMC and BIOS, are:
baud rate 115200, no flow control, terminal type VT100, 8 data bits, No Parity,
1 Stop Bit.

2.3. BMC SPI Flash

The three onboard SPI Flash chips are used for holding Primary and Secondary BMC images, and BIOS image. Winbond W25Q256/257 and Numonyx N25Q256 are default supported SPI flashes, other brands are also supported but not fully tested.

2.4. Network Interfaces



The TiogaPass platform uses Option 3 of the Management Network Interface from OCP spec. Intel I210-AT NIC used for RMII/NCSE interfaces, which passes both BMC and management data traffic with a RJ45 port. There is a Mezzanine Card which compatible with Intel v2.0 Motherboard, which holds two SFP interfaces with up to 10G data rate. There is also PCIe slot can be used for NCSI Raiser Card, to hold the second NCSI interfaces.

2.5. LAN Interface

Supports dedicated and shared LAN interface for Out-of-Band access to the Service Processor.

By default MAC will be auto generated and configured if it is not configured by the user. Supported IPMI commands are listed in section 4.

Example:

```
ipmitool -H <BMC IP> -U root -I lanplus -P 0penBmc raw 0x6 0x1    → Get Device ID
ipmitool -H <BMC IP> -U root -I lanplus -P 0penBmc lan print 1    → Get Lan Info
ipmitool -H <BMC IP> -U root -I lanplus -P 0penBmc chassis power <on/off/cycle/reset/status>
ipmitool -H <BMC IP> -U root -I lanplus -P 0penBmc sensor
ipmitool -H <BMC IP> -U root -I lanplus -P 0penBmc sdr
```

2.6. KCS Interface

KCS interface is supported in the firmware for In-band interface for Host to BMC communication. Firmware supports only SMS interface, SMM interface not supported.

Example: ipmitool raw 6 1

2.7. Sideband Interface

BMC supports the sideband network interface function. Shared lan between BMC and Host. By default the ETH0 is the sideband interface while the ETH1 is the dedicated network interface. It varies based on platform design. The following command can be tested using the either of the IP addresses.

Example: ipmitool -H <BMC IP> -I lanplus -U root -P 0penBmc raw 0x6 0x1

2.8. Sensor Support

Sensor configuration and monitoring will be done through entity manager. Temperature, Voltage and Fan sensors are supported. It can be accessible through REST Over D-bus and IPMI.

Sensor Reading Through IPMI:

ipmitool -H <IP> -U root -P 0penBmc -I lanplus sensor

	Chassis Intrusio	0x0	discrete	0x0000	na	na	na
na	na	na					
	ACPI State	0x0	discrete	0x0000	na	na	na
na	na	na					
	SEL	0x0	discrete	0x0000	na	na	na
na	na	na					
	WATCHDOG2	0x0	discrete	0x0000	na	na	na
na	na	na					
	MB FAN0 TACH	9212.000	RPM	nc	na	490.000	na
8526.000	11466.000	na					
	MB FAN1 TACH	3332.000	RPM	ok	na	490.000	na
8526.000	11466.000	na					
	MB INLET REMOTE	39.000	degrees C	ok	na	na	na
na	na	na					
	MB INLET TEMP	45.000	degrees C	cr	na	na	na
na	40.000	na					
	MB OUTLET REMOTE	32.000	degrees C	ok	na	na	na
na	na	na					

	MB OUTLET TEMP	33.000	degrees C	ok	na	na	na
na	90.000	na					
	MEZZ SENSOR REMO	0.000	degrees C	ok	na	na	na
na	95.000	na					
	MEZZ SENSOR TEMP	91.000	degrees C	ok	na	na	na
na	na	na					
	MB P3V BAT	3.138	Volts	ok	na	2.735	na
na	3.731	na					
	MB P1V05	1.044	Volts	ok	na	0.937	na
na	1.150	na					
	MB P3V3	3.302	Volts	ok	na	2.976	na
na	3.612	na					
	MB P3V3 STBY	3.302	Volts	ok	na	2.976	na
na	3.612	na					
	MB P5V	4.940	Volts	ok	na	4.524	na
na	5.486	na					
	MB P5V STBY	4.940	Volts	ok	na	4.524	na
na	5.486	na					
	MB P12V	11.970	Volts	ok	na	10.773	na
na	13.230	na					
	MB PVNN PCH STB	0.994	Volts	ok	na	0.760	na
na	1.101	na					

2.9. System Event Log Support

BMC FW supports system event logging. SEL list and add can be done using the standard IPMI commands.

For example: `ipmitool -U root -P OpenBmc -I lanplus -H <BMC IP> sel list`

In the **Server Health** option, click **System log** tab where SEL can be viewed on web UI as shown below.




Figure 1 System Log

2.10. FRU Device Support

BMC FW supports the IPMI FRU devices support. FRU device configuration can be done through Entity manager, read and write FRU data to eeprom are supported.


```
root@tiogapass:~# ipmitool -U root -P OpenBmc -I lanplus -H 172.31.1.2
FRU Device Description : Builtin FRU Device (ID 0)
Chassis Type           : Rack Mount Chassis
Chassis Part Number    : 67890
Chassis Serial         : 12345
Chassis Extra          : 13579
Chassis Extra          : 24680
Chassis Extra          : .....
Chassis Extra          : .....
Board Mfg Date         : Mon Jul 10 16:30:00 2017 UTC
Board Mfg              : Wiwynn
Board Product          : S2600Tioga
Board Serial           : .....
Board Part Number      : .....
Board Extra            : .....
Board Extra            : .....
Product Manufacturer   : Wiwynn
Product Name           : S2600Tioga
Product Part Number    : 123456789
Product Version        : .....
Product Serial         : 123454321
```

Figure 2 FRU Device Support

2.11. BMC Firmware Upgrade Support

Four types of flashing methods are supported:

1. Soc Flash
2. Dediprog
3. TFTP flash
4. Web UI flash

Note : For SOC Flash, Dediprog and TFTP “<image_name>.mtd ” image should be used.

For WEB Flash “<image_name>.mtd.tar” or “<image_name>.mtd.tar.all” image should be used.

2.11.1 SOC Flash Utility

Download and install the soc flash utility from aspeed website:

<https://www.aspeedtech.com/support.php>

Socflash utility should be installed on the host OS (Linux) side.

Run the below command:

socflash if=<firmware file name> of=<backup filename>

2.11.2 Dediprog

Hardware Tool: DediProg* SF600 or similar tool

Software: DediProg Software latest version

Following are the steps to perform using Dediprog Software.

- a) Take the BMC EEPROM from the BMC socket and place in DediProg programming socket.
- b) Launch the DediProg software and select SPI Device.

- c) Upload the firmware image file.
- d) Click **Batch** and then the flashing starts.

2.11.3 TFTP Flash

Reset or power cycle the server and use key presses to stop BMC booting at the U-Boot prompt.

- a) Set the environment value:
Set Tftp server ip and ethaddr and Get dynamic ip address
Example:
setenv serverip <IP Address>
setenv ethaddr <MAC>
setenv eth1addr <MAC>
setenv ethact ftgmac@1e680000
dhcp

- b) Download image from tftp server:

Example:
tftp 0x83000000 <image>


- c) Probe and flash the image:

Example:
sf probe 0
sf update 0x83000000 0x00 0x2000000
saveenv
reset


2.11.4 Web UI flash

Please refer to section 2.12 for login WebUI and navigate inside the WebUI interface.


- a) Login to UI (<https://<BMC IP>>)
- b) Navigate to **Server Configuration -> Firmware**




- c) Scroll to the **Upload image from local or download from tftp server**.
- d) Click choose a file and locate the tar file to upload. Click **Upload firmware**.




- e) Scroll back up to the top and the user can view another image with actions **Activate** and **Delete**. Choose **Activate** to activate the recently flashed image.



f) Choose the option as restart the BMC. A sample screenshot is displayed below.



g) User can view the message stating that “BMC is resetting” as shown in the below screenshot.



- h) Now, UI gets logout and BMC will reboot it.
- i) 5-10 minutes for the BMC to flash and reset.

2.12. WebUI Support

BMC FW supports a web server based on the bmcweb implementation and phosphor web UI front end. This can be accessed using the BMC IP address. A sample screenshot of the login page is given below.

1. Use valid user credentials (default are root/openBmc, note it's not O, it's zero :) to login.




Figure 3 Web UI support

2. Once logged in the default idle screen as shown below.







Figure 4 Default Idle Screen

- Each of the options on the left panel opens up multiple other related options for the user. For example **Server Health** option displays the Event log, Hardware status, Sensors and System logs. For instance, Sensor page is displayed as below. This has all the sensors showing with their current readings and status.

OpenBMC


tiogapass
172.31.1.202

Server health >
 **Critical**

Server power >
 **Off**

Data last refreshed
Apr 4, 2021 12:3

Overview
Health
System log
Event log
Hardware status
Sensors
Control
Configuration
Access

Sensors

All sensors present in the system

FILTER SENSORS

FILTER BY SEVERITY

All
Critical
Warning
Normal


Sensors (19)	Low critical	Low warning	Current	High warni
MB INLET REMOTE TEMP	° C	° C	41.563° C	° C
 MB INLET TEMP	° C	° C	44.813° C	° C

Figure 5 Sensor

2.13. KVM Support

BMC FW provides support to access the server console via KVM. Click **Server Control** → **KVM**, to access the KVM. A sample screenshot is displayed below.




Figure 6 KVM Support

2.14. Reboot BMC

We can reboot the BMC through web UI. Click **Server Control** → **Reboot BMC**, to reboot the BMC. A sample screenshot is displayed below.




Figure 7 Reboot BMC

2.15. Server Power Operation

Chassis power operation are supported through web UI. Click **Server Control** → **Server Power Operation**, to reboot the BMC. A sample screenshot is displayed below.




Figure 8 Reboot BMC

2.16. NTP Support

NTP support for time setting is available using the WebUI. After login with the valid user credentials (root/OpenBmc), click **Server configuration > Date and Time setting** option. BMC time can be set either manually or automatically using NTP and the specified NTP server. One or more servers can be added using the button as shown below.




Figure 9 NTP Support

2.17. BMC Network Settings

BMC Web UI supports option to modify and edit the BMC network settings. On the default login page, select the BMC Network Setting option to access this page as shown below. The same can be accessed by clicking **Server configuration → Network Settings**.

BMC network settings

COMMON SETTINGS

HOSTNAME	NETWORK INTERFACE	MAC ADDRESS
tiogapass	eth0	ee:8c:3a:ae:46:60

IPV4 SETTINGS

☒ OBTAIN AN IP ADDRESS AUTOMATICALLY USING DHCP

☐ ASSIGN A STATIC IP ADDRESS

IPV4 ADDRESS	GATEWAY	NETMASK PREFIX LENGTH
172.31.1.202		20

Add IPV4 address

DNS SETTINGS

DNS SERVER 1

Figure 10 BMC Network settings

2.18. User Management Support

BMC FW supports User management including adding a new user, deleting an existing user, modifying the privileges of an existing user, etc. This can be done using the Access Control option on the left side panel of the BMC web UI. Select Local users on the extended left panel to view the page and manage users.




Figure 11 User Management support

LDAP support is currently disabled on this release of BMC FW.

2.19. IPMI 2.0 and DCMI 1.5 support:

IPMI 2.0 based implementation is supported on the BMC FW. Not all the mandatory commands are implemented in the current version of the FW. The list of supported commands is listed in section 4. IPMI based host power controls are supported. Please refer release document for known issues.

DCMI 1.5 capability is supported on this release of the BMC FW. The list of supported commands is specified in section 4. Please refer release documentation for details on each of supported commands.

2.20. vMedia Support

BMC FW supports virtual media. User navigates to “Server control → Virtual Media” page, after logging in on the webUI. As shown below there will be option to choose a file.




Figure 12 vMedia Support

User selects file and pushes 'start' button to establish websocket connection. Then you see the following page showing active session.




Figure 13 Virtual Media

The nbdServerService on FW provide ability for user to navigate away from the page and return with the ability to see the current active sessions. For example, you can upload Ubuntu image file and mount virtual media device from host console. Then you will be able to see Ubuntu image file. Finally, when connection is stopped, 'USB disconnect' log would be appear on host console.

2.21. SSL Certificate Support

BMC FW supports SSL Certificate. User navigates to “Access → SSL Certificate” page, after logging in on the webUI. As shown below there will be options to add new certificate, generate CSR.

OpenBMC

tiogapass
172.31.1.202

Server health > **Warning**

Server power > **Running**

Data last refreshed
Apr 6, 2021 1:2

Health

- System log
- Event log
- Hardware status
- Sensors

Control

- Server power operations
- Manage power usage
- Server LED
- Reboot BMC
- Restore Factory Default
- Serial over LAN console
- KVM
- Virtual Media

Configuration

- Network settings
- SNMP settings
- Firmware

SSL certificates

[+ Add new certificate](#) [+ Generate CSR](#)

Certificate	Issued by	Issued to	Valid from	Valid until
HTTPS Certificate	testhost	testhost	Apr 2, 2021	May 2021

2.22. LDAP Support

BMC FW supports configuring LDAP settings and manage role groups.

OpenBMC

tiogapass
172.31.1.202

Server health > **Warning**

Server power > **Running**

Data last refreshed
Apr 6, 2021 1:3

Health

- System log
- Event log
- Hardware status
- Sensors

Control

- Server power operations
- Manage power usage
- Server LED
- Reboot BMC
- Restore Factory Default
- Serial over LAN console
- KVM
- Virtual Media

Configuration

- Network settings

LDAP

Configure LDAP settings and manage role groups.

Settings

☒ **Enable LDAP authentication**
LDAP authentication must be enabled to modify role groups.

☐ Secure LDAP using SSL

A CA certificate and LDAP certificate are required. One or more are missing.

[Go to SSL certificates](#)

SERVICE TYPE

☐ Open LDAP

☒ Active directory

SERVER URI **BIND DN**


ldap://172.31.32.2 cn=Administrator,c

BASE DN **USER ID ATTRIBUTE**

2.23. Redfish Support

BMC FW supports Redfish, here are some examples:

GET Schema Init - <http://{{ip}}/redfish/v1/>



System Collection - <http://{{ip}}/redfish/v1/Systems/>



3. BMC Internal Tool Usage

3.1. GPIO Utilities

There are a few GPIO utilities supported on the BMC FW. They can be used to set/get state on the GPIO lines, set/get direction of a GPIO line etc.

1. **gpiodetect:**

Usage: gpiodetect

List all GPIO chips; print their labels and number of GPIO lines.

Example:

```
root@wolfpass:~# gpiodetect  
gpiochip0 [1e780000.gpio] (232 lines)
```

2. gpiofind:

Usage: gpiofind <name>

Find a GPIO line by name. The output of this command can be used as input for gpioget/set.

Example:

```
root@wolfpass:~# gpiofind SIO_S3
gpiochip0 192
```

3. gpioset:

Usage: gpioset [OPTIONS] <chip name/number> <offset1>=<value1> <offset2>=<value2> ...

Set GPIO line values of a GPIO chip and maintain the state until the process exits.

Options:

- v, --version: display the version and exit
- l, --active-low: set the line active state to low
- m, --mode=[exit|wait|time|signal] (defaults to 'exit'):
tell the program what to do after setting values
- s, --sec=SEC: specify the number of seconds to wait (only valid for --mode=time)
- u, --usec=USEC: specify the number of microseconds to wait (only valid for --mode=time)
- b, --background: after setting values: detach from the controlling terminal

Modes:

- exit: set values and exit immediately
- wait: set values and wait for user to press ENTER
- time: set values and sleep for a specified amount of time
- signal: set values and wait for SIGINT or SIGTERM

***Note:** The state of a GPIO line controlled over the character device reverts to default when the last process referencing the file descriptor representing the device file exits. This means that it's wrong to run `gpioreset`, have it exit and expect the line to continue being driven high or low. It may happen if given pin is floating but it must be interpreted as undefined behavior.*

4. `gpioget`:

Usage: `gpioget` [OPTIONS] <chip name/number> <offset 1> <offset 2> ...
Read line value(s) from a GPIO chip

Options:

-v, --version: display the version and exit
-l, --active-low: set the line active state to low

Example:

```
root@wolffpass:~# gpioget gpiochip0 2
0
```

5. `gpioinfo`:

Usage: `gpioinfo` [OPTIONS] <gpiochip1>..
Print information about all lines of the specified GPIO chip(s) (or all gpiochips if none are specified).

6. `gpiomon`:

Usage: `gpiomon` [OPTIONS] <chip name/number> <offset 1> <offset 2> ...
Wait for events on GPIO lines and print them to standard output

Options:

-v, --version: display the version and exit
-l, --active-low: set the line active state to low
-n, --num-events=NUM: exit after processing NUM events
-s, --silent: don't print event info
-r, --rising-edge: only process rising edge events
-f, --falling-edge: only process falling edge events
-b, --line-buffered: set standard output as line buffered
-F, --format=FMT specify custom output format

Format Specifiers:

%o: GPIO line offset
%e: event type (0 - falling edge, 1 rising edge)
%s: seconds part of the event timestamp
%n: nanoseconds part of the event timestamp

3.2. I2C Tools

1. `i2cdetect`:

Usage: `i2cdetect` [-y] [-a] [-q|-r] I2CBUS [FIRST LAST]
`i2cdetect` -F I2CBUS
`i2cdetect` -l
I2CBUS is an integer or an I2C bus name

If provided, FIRST and LAST limit the probing range.

2. i2cdump:

Usage: i2cdump [-f] [-y] [-r first-last] [-a] I2CBUS ADDRESS [MODE [BANK [BANKREG]]]
I2CBUS is an integer or an I2C bus name
ADDRESS is an integer (0x03 - 0x77, or 0x00 - 0x7f if -a is given)
MODE is one of:
b (byte, default)
w (word)
W (word on even register addresses)
s (SMBus block)
i (I2C block)
c (consecutive byte)
d (double word)
Append p for SMBus PEC

3. i2cget:

Usage: i2cget [-f] [-y] [-a] I2CBUS CHIP-ADDRESS [DATA-ADDRESS [MODE] [LENGTH]]
I2CBUS is an integer or an I2C bus name
ADDRESS is an integer (0x03 - 0x77, or 0x00 - 0x7f if -a is given)
MODE is one of:
b (read byte data, default)
w (read word data)
c (write byte/read byte)
i (read I2C block data)
Append p for SMBus PEC
LENGTH is length for block data reads

4. i2cset:

Usage: i2cset [-f] [-y] [-m MASK] [-r] [-a] I2CBUS CHIP-ADDRESS DATA-ADDRESS [VALUE]
... [MODE]
I2CBUS is an integer or an I2C bus name
ADDRESS is an integer (0x03 - 0x77, or 0x00 - 0x7f if -a is given)
MODE is one of:
c (byte, no value)
b (byte data, default)
w (word data)
i (I2C block data)
s (SMBus block data)
Append p for SMBus PEC

3.3. obmc-console

obmc-console is used to redirect serial (UART) over ssh. We can specify host serial port in obmc-console-server/systemd service. There are two methods to get remote host console:

- Standalone tool from bmc: obmc-console-client
- Using ssh: ssh -p2200 root@<BMC IP>

3.4. Accessing Devices from U-boot

1. Read memory:

md <memory register offset address>

Example: Display USB1.1 HID Controller Function Control and Status

md 0x1e6e1000

2. Write memory:

mw <memory register offset address> <value>

Example: Display USB1.1 HID Controller Function Control and Status:

md 0x1e6e1000 0x00000003 → To enable USB connection and Low speed.

***Note:** The above command will apply the 32 bit value into memory offset.*

Please refer AST data sheet for address mapping and register offset.

4. Supported IPMI Commands

Net Function	Command	Command Name	Comments
<i>Application</i>			
0x06	0x01	Get Device ID	
0x06	0x02	Cold Reset	
0x06	0x08	Get Device GUID	
0x06	0x38	Get Channel Authentication Capabilities	
0x00	0x01	Get Chassis Status	
0x00	0x09	Get System Boot Options	Only parameter 5 is supported(as per IPMI Spec)
0x00	0x0F	Get POH Counter	
<i>SensorEvent</i>			
0x04	0x20	Get Device SDR Info	
0x04	0x21	Get Device SDR	
0x04	0x22	Reserve Device SDR Repository	
0x04	0x2D	Get Sensor Reading	
<i>Storage</i>			
0x0a	0x10	Get FRU Inventory Area Info	
0x0a	0x11	Read FRU Data	
0x0a	0x12	Write FRU Data	
0x0a	0x20	Get SDR Repository Info	
0x0a	0x23	Get SDR	
0x0a	0x40	Get SEL Info	
0x0a	0x44	Add SEL Entry	
0x0a	0x43	Get SEL Entry	
0x0a	0x42	Reserve SEL	
0x0a	0x47	Clear SEL	
0x0a	0x48	Get SEL Time	
0x0a	0x49	Set SEL Time	
<i>Transport</i>			

0x0c	0x01	Set LAN Configuration Parameters	SUPPORTED [Authentication type, ip-address, ip-address-source, MAC address, subnet-mask]
0x0c	0x02	Get LAN Configuration Parameters	SUPPORTED [Authentication type ,ip-address, ip-address-source, MAC address, subnet-mask]
0x0c	0x21	Set SOL Configuration Parameters	SOL Payload Port Number, SOL Payload Channel, SOL retry, SOL Authentication not supported
0x0c	0x22	Get SOL Configuration Parameters	SOL retry, SOL Authentication not supported
DCMI			
0x2c	0x01	Get DCMI Capability Info	parameter 5 is not supported, will get default values back
0x2c	0x03	Get Power Limit	
0x2c	0x04	Set Power Limit	Exception Actions, Correction Time Limit, Sampling period not working
0x2c	0x05	Activate Power Limit	
0x2c	0x06	Get Asset Tag	
0x2c	0x08	Set Asset Tag	
0x2c	0x09	Get Management Controller Id String	
0x2c	0x10	Get Temperature Reading	
0x2c	0x12	Set DCMI Configuration Parameters	SUPPORTED [Activate DHCP]
0x2c	0x13	Get DCMI Configuration Parameters	SUPPORTED [Activate DHCP]

lan	print, set, alert print, alert set, stats clear
chassis	status, power, policy, poh, bootdev, bootparam
power	status, on, off, reset
event	
mc	reset, cold, info

sdr	
sensor	
fru	print, read, write