



# **VA8801 Series**

*Rev. 0.1*

**FITI\_VA8801\_ToolKit**

**AI SoC**

*fitipower integrated technology inc.*

**Table of Contents**

*Table of Contents 1*

<b>1.</b>	<b>SYSTEM REQUIREMENTS .....</b>	<b>2</b>
1.1	Windows 10.....	2
<b>2.</b>	<b>HARDWARE REQUIREMENTS.....</b>	<b>2</b>
2.1	VA8801 Demo board.....	2
<b>3.</b>	<b>SOFTWARE TOOL.....</b>	<b>2</b>
3.1	FITI_VA8801_ToolKit .....	2
<b>4.</b>	<b>FLASH BIN FILE BY UART .....</b>	<b>2</b>

**FITIPOWER CONFIDENTIAL**  
**NO DISCLOSURE**

# 1. SYSTEM REQUIREMENTS

1.1 Windows 10

# 2. HARDWARE REQUIREMENTS


2.1 VA8801 Demo board

# 3. SOFTWARE TOOL


3.1 FITI\_VA8801\_ToolKit

# 4. FLASH BIN FILE BY UART


4.1 Connect VA8801 to PC with Type C cable or micro USB, after plug in power cable, press button up for power on.



4.2 Connect **UART com port (UART3)** to PC with **UART cable**.




4.3 Check UART3 com port number in PC (For example : COM9)



4.4 Click **FITI\_VA8801\_ToolKit\_V1.0.0.0.exe**.

名稱	修改日期	類型	大小
FITI_VA8801_ToolKit_V1.0.0.0.exe	2024/1/30 上午 10:52	應用程式	56,950 KB
WindowsFormsControlLibrary_Monitor.dll	2024/1/30 上午 10:51	應用程式擴充	391 KB


4.5 Select COM port, baud rate and click connect icon.




4.5.1 After connected, the connect icon show green color.



#### 4.6 Generate Flash bin file.




4.6.1 After finished, you could see flash bin file in the destination folder.



- 4.7 Set the Boot mode to upgrade mode.(Press PIN SW\_QSCLK, QIO0101 and PIN QIO2103 to UP)



- 4.8 Reboot device.







- 4.9 Set the Boot mode to flash upgrade mode.  
(Press PIN SW\_QSCLK and PIN QIO2103 to Up, press PIN QIO0101 to down)




- 4.10 Please check device version whether it is 8801AA01.




- 4.11 Select to 8 MB flash (recommend). (Press PIN SW\_QSCLK, PIN QIO0101 and PIN QIO2103 to down). If you want to flash 256 MB flash, please press PIN SW\_QSCLK, PIN QIO0101 and PIN QIO2103 to UP.



- 4.12 After setting boot mode, you could start to flash bin file,








FITIPOWER  
NO DISC

4.13 After flash done, the status bar changes to **PASS**.



4.14 Reboot device and check the UART log.

Enter AP code.=====Hello World=====