

Partner: Yealink  
Models: AVHub  
Device Type: Video Conferencing



## GENERAL INFORMATION

<b>SIMPLWINDOWS NAME:</b>	Yealink Room System AVHub v1.1
<b>CATEGORY:</b>	Video Conferencing
<b>VERSION:</b>	1.1
<b>SUMMARY:</b>	This module controls one AVHub that is connected to the Yealink MCore Mini-PC.
<b>GENERAL NOTES:</b>	
<b>CRESTRON HARDWARE REQUIRED:</b>	3-Series processor or 4-Series processor
<b>SETUP OF CRESTRON HARDWARE:</b>	
<b>VENDOR FIRMWARE:</b>	Yealink RoomConnect 2.33.0.0
<b>VENDOR SETUP:</b>	See MCore module help file for instructions on setting up Central Control.

Partner: Yealink  
Models: AVHub  
Device Type: Video Conferencing



## PARAMETERS:

<b>Command Processor Id</b>	Integer value of the command processor instance that this module will be managed by.
<b>Serial Number</b>	The serial number of the AVHub. Found on the bottom of the hub and within the RoomConnect software.

Partner: Yealink  
Models: AVHub  
Device Type: Video Conferencing

**CONTROL:**

<b>Layout Enable</b>	D	Pulse to enable camera layout mode.
<b>Layout Disable</b>	D	Pulse to disable camera layout mode.
<b>Layout Fullscreen</b>	D	Pulse to set the camera layout mode to fullscreen.
<b>Layout Division</b>	D	Pulse to set the camera layout mode to division. Use the Layout_Division_Num_Screens parameter to set the number of screens.
<b>Layout Surround</b>	D	Pulse to set the camera layout mode to surround. Use the Layout_Surround_Num_Screens parameter to set the number of screens shown around the main screen.
<b>Layout Division Num Screens</b>	D	Integer value of the number of screens to display in division mode. Range is 2d to 9d.
<b>Layout Surround Num Screens</b>	D	Integer value of the number of screens to display around the main screen in surround mode. Range is 1d to 8d.
<b>Camera At Position 1- 9</b>	A	The camera id value of the camera to be displayed at the position. Range is 1d to 9d.
<b>Divisible Disable</b>	D	Pulse to disable Divisible Meeting Room function.
<b>Divisible Standalone</b>	D	Pulse to set Divisible Meeting Room function.
<b>Divisible Merged</b>	D	Pulse to set Divisible Meeting Room function.
<b>Divisible Master</b>	D	Pulse to set Divisible Meeting Room function.

Partner: Yealink  
Models: AVHub  
Device Type: Video Conferencing



## FEEDBACK:

<b>Is Initialized</b>	D	Indicates the module is has successfully connected with the MCore module.
<b>Camera At Position 1– 9 Name</b>	S	The name of the camera displayed at the position. This is updated when the Camera_At_Position_0-9 input is set. It is implemented for ease of UI programming. It is not true feedback.

Partner: Yealink  
Models: AVHub  
Device Type: Video Conferencing

**TESTING:**

<b>OPS USED FOR TESTING:</b>	CP3 1.603.4242.34642
	CP4 2.8003.00056
<b>SIMPL WINDOWS USED FOR TESTING:</b>	4.3
<b>CRES DB USED FOR TESTING:</b>	226.05
<b>DEVICE DATABASE:</b>	200.360
<b>SYMBOL LIBRARY USED FOR TESTING:</b>	1207
<b>SAMPLE PROGRAM:</b>	Yealink Room System Demo CP3 v1.1.smw
<b>REVISION HISTORY:</b>	v1.0 – Initial Release
	v1.1 – No updates to this module