




Innovation First, Inc.

C-BOT Software Installation Guide




1. Begin the installation

- a. Check PC System Requirements
 - i. Hardware:
 1. Pentium class processor
 2. 32MB RAM (128MB recommended)
 3. 85MB of free hard-disk space
 - ii. Supported Operating Systems:
 1. Windows 98 SE
 2. Windows ME (Microchip MPLAB only; IFI Loader will not work on ME)
 3. Windows NT 4.0 SP6a Workstations (NOT Servers)
 4. Windows 2000 SP2 or higher
 5. Windows XP Home and Professional
- b. Reboot your PC.
- c. Insert the C-BOT CD into PC's CD-ROM drive.
- d. Setup should automatically run, but if not:
 - i. Click on the "Start" menu and select "Run".
 - ii. Click "Browse...", find SetupCbot.exe, and click "OK".
- e. Click on "Install Applications" in the interface.




2. Install MPLAB IDE v6.30

- a. Click on "1. Install MPLAB IDE v6.30" in the interface.




- b. Click "Next >", then "Install >", then "Next >".


- c. Select “I Agree” and click “Next >”.



- d. Click “Next >” five times until installation begins.
- e. Wait for installation to finish and progress bar to disappear.
- f. NOTE: If you have previously installed MPLAB IDE on your computer, you might see two messages titled “Update Tool Path”. If so you should click “Yes” for both messages.
- g. Select “No” and click “Next >”.




- h. Click “Next >”, then “Continue”, then “Finish”.
- i. Wait for web browser windows to open. Ignore them.
- j. If the following window appears, click “Cancel”. You do not want to reboot yet.




- k. Close the web browser windows, ignoring their contents.
- l. Click “Finish >”.

3. Install MPLAB C18


- a. Click on “Go To Step 2” in the lower right corner of the interface.



- b. Click on “Install MPLAB C18 v2.20 for PIC18F8520”.




- c. Click “Next >” four times.
- d. Click to put checkmarks in all of the checkboxes:




- e. Click “Next >” twice.
- f. Wait for installation to finish and progress bar to disappear.
- g. Click “Finish >”.
- h. If a window appears asking you to reboot, click “Cancel” and do not reboot yet.

4. Install IFI Loader

- a. Click on “Install IFI Loader”.



- b. Click “OK”.
- c. Click on the large button in the upper left corner with a picture of a computer.



- d. Click “Continue”.
- e. Click “OK”.
- f. Click “Exit” in the lower left corner of the interface.

5. Reboot your PC.

NOTE: For instructions on using the installed software to program your IFI Robot Controller, please refer to the 2004 Programming Reference Guide available from www.InnovationFirst.com.