

Faithtech

Programmable DC Power Supply

User Manual

(FTP9000 Series)

©Copyright Faithtech

Version V1.07

2024-2

Introduction

Dear users :

First of all, thank you for choosing shenzhen Faith technology co., LTD. (hereinafter referred to as the Faithtech), FTP9000 series high power wide range programming power system (hereinafter referred to as FTP9000 series). This User manual (hereinafter referred to as the manual) is applicable to the FTP9000 series and includes detailed information on installation, operation and specifications of the equipment.

In order to ensure safe and correct use of the equipment, please read this manual carefully before use, especially the safety precautions.

Please keep this manual for use in the process of inspection.

Notice

The copyright of this manual belongs to our company. The information contained in the manual is for the user's reference only and is subject to change without notice.

The Company is not responsible for errors that may be contained in this manual or damages caused by the provision, implementation and use of this manual.

The warranty service

The company guarantees that the specifications and use characteristics of this instrument fully meet the technical indicators claimed in the manual, and the raw materials and manufacturing processes used in this product are strictly checked to ensure that the product is stable and reliable.

Since the acquisition date, one year warranty, the product in normal use and maintenance condition of what's going on fault, the company responsible for free maintenance. For free maintenance products, users need to prepay the one-way freight to the company's maintenance department, and the return freight shall be borne by the company. If the product is returned to the factory from another country for repair, all freight, duties and other taxes shall be borne by the customer.

Limitation of warranty

This warranty is limited to the equipment host. The Company is not responsible for free repair of damage caused by incorrect use, unmanaged, unauthorized modification, use under abnormal environment and force majeure factors, and will submit the valuation form before the repair.

No OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY, REASONABILITY AND FITNESS FOR PARTICULAR APPLICATIONS, WHETHER IN CONTRACT, CIVIL NEGLIGENCE, OR OTHERWISE, ARE MADE. The company shall not be liable for any special, incidental or indirect damages.

Safety Summary

In the process of operating and using the equipment, please strictly observe the following safety instructions. Failure to comply with the following precautions or specific warnings as indicated in other sections of this manual may impair the protection provided by the device.



















The Company is not responsible for the consequences caused by the user's non-compliance with these precautions.

Safety instructions

Please ground it reliably	Before turning on the equipment, make sure the equipment is reliably grounded to prevent electric shock
3 phase 380VAC Input	The input wire meets the specified standards; Be sure to install a protective cover to prevent electric shock.
Output terminal cable connection	The input wire meets the specified standards; Be sure to install a protective cover to prevent electric shock.
Do not open the instrument housing	The operator shall not open the equipment shell; Non-professional personnel do not perform maintenance or adjustment.
Do not use in dangerous environment	Do not use the equipment in inflammable and explosive environment.

Safety mark

Please refer to the following table for the explanation of international symbols used in the case and user manual of this product.

Symbol	Meaning	Symbol	Meaning
	Direct current		Zero or neutral line
	AC current		Line of fire
	AC/DC current		Power on
	3 phase current		Power off
	Ground		Backup power supply
	Protective grounding		The button switch is pressed
	Connect the enclosure or chassis		Button switch popup
	Signal ground		Be careful with the shocks
WANNING	Sign of danger		High temperature Warning
Caution	be careful		Warning

Version Revision Record

Date	Version	Revised chapter
2019-7	1.0	Complete this manual
2020-9	1.01	Add 750V specifications and models; Add the installation size of 20kW ~ 30kW power grade chassis
2021-1	1.02	Added 1200V specification model;
2021-3	1.03	Update the voltage model
2021-8	1.04	Add external control signal 0-10V gear description
2022-11	1.05	Added PV curve function
2024-2	1.07	Improve accuracy parameters

Content

1. GENERAL DESCRIPTION	6
1.1 Overview	6
1.2 Main features	6
1.3 Dimension diagram	7
1.3.1 Model of 5kW, 10kW, 15kW	7
1.3.2 Model of 6kW, 12kW, 18kW	8
1.3.3 Model of 20kW, 25kW, 30kW	9
1.3.4 Model of 24kW, 30kW, 36kW	10
1.4 Model Naming	10
1.5 Specification sheet	11
2. QUICK GUIDE	16
2.1 Checking Goods	16
2.2 Front Panel	17
2.3 Keyboard	18
2.4 Screen Display	19
2.5 Rear Panel	20
2.6 Installing	21
2.6.1 Preparation For Use	22
2.6.2 Requirements of Input Power	22
2.6.3 Power ON Self Check	22
2.7 Connection	23
2.7.1 Input Connection	23
2.7.2 Input Connection for Multiple Power Supplies	23
2.7.3 Output Connection	24
2.7.4 Remote Sensing Connection	24
2.7.5 PRO-INT Analog Interface	25
3. FUNCTION INTRODUCTION	26
3.1 Local & remote operation mode	26
3.2 Menu Layout	26
3.2.1 Set Menu	26
3.2.2 System Menu	28
3.2.3 Edit Menu	28
3.2.4 About Menu	28
3.3 Static Output Function	29
3.3.1 Power supply output modes	30
3.3.2 Limit Voltage/Current/Power Set	30
3.4 Voltage Slew Rate And Current Slew Rate	31
3.5 CV/CC Priority Start function	31
3.6 Output Control	32
3.7 Analog interface (optional PRO-INT interface)	32
3.7.1 Analog Programming	32

3.7.2 External Control	34
3.7.3 Voltage, Current Monitoring Output	35
3.7.4 Output Mode & Status Monitoring	35
3.8 Protection	36
3.9 Save And Recall	37
3.10 Power-down Save	38
3.11 Keyboard Lock And Unlock	39
3.12 Sequence (SEQ) Function	39
3.13 Internal Resistance Simulation (RESI)	41
3.14 Voltage ramp-up, ramp-down (RAMP)	43
3.15 Master-slave Parallel	44
3.15.1 Master-slave parallel connection	44
3.15.2 Master-slave parallel setting	45
3.15.3 Master-slave parallel function operations	46
3.16 Photovoltaic Simulation Function (PV-SIM) (Optional)	48
4. COMMUNICATION INTRODUCTION	52
4.1 Communication Setup	52
4.2 Voltage, current acquisition speed	53
4.3 Communication Interfaces	53
4.3.1 USB (Serial)	53
4.3.2 LAN	54
4.3.3 CAN	54
4.3.4 RS485	54
4.4 Communication Protocol	55
4.4.1 SCPI protocol	55
4.4.2 Modbus protocol	55
4.4.3 CANopen protocol	56
5. TROUBLESHOOTING	57
6. APPENDIX	58

1. General Description

1.1 Overview

FTP9000 series high-power programmable DC power supply has the characteristics of high power density, high power factor, high efficiency, and wide range of output. Its wide range voltage / current output and automatic constant power function can greatly increase the application coverage. FTP9000 series DC power supply output power 5kW up to 180kW in a single unit, and expandable up to 1800kW when paralleling 10 identical models. Its voltage output up to 2250V, current up to 6120A.




For bench top applications, this series provides an intuitive user interface with full keypad and rotary knob. System integrators benefit from the standard USB (virtual SERIAL) and LAN interfaces supporting both SCPI commands and ModBus RTU protocol. Free application software, programming manual and a complete set of development DLLs are available to reduce programming time and increase productivity. The application software allows users to control the power supply, execute test sequences, or log measurements.

1.2 Main features


- Output voltages: 80 V up to 2250 V;
- Output current: 20 A up to 6120 A;
- Output power: 5 kW up to 180 kW, expandable up to 1800 kW;
- CV, CC, CP operation modes;
- Easy Master-Slave parallel;
- Precision V & I measurement;
- High speed programming;
- Programmable sequence;
- Voltage & current slew rate control;
- CV / CC priority;
- Voltage ramp function;
- Wide operating region for output;
- Internal resistance simulating;
- Remote sense compensation;
- Optional analog programming & monitoring interface;
- \pm OVP, \pm OCP, \pm OPP, OTP, \pm LVP;
- Voltage / current / power limit;
- Standard LAN, USB (serial), optional RS485, GPIB or CAN ports;
- SCPI and ModBus RTU protocol;

1.3 Dimension diagram




1.3.1 Model of 5kW, 10kW, 15kW




1.3.2 Model of 6kW, 12kW, 18kW



1.3.3 Model of 20kW, 25kW, 30kW



1.3.4 Model of 24kW, 30kW, 36kW



1.4 Model Naming

FTP9 <u>XXXX</u> - <u>XXXX</u> - <u>XXXX</u> <u>XX</u>					
050 = 5kW	80 = 80V	30 = 30A	None = LAN, USB	None = without analog interface	
100 = 10kW	400 = 400V	500 = 500A	G = LAN, USB + GPIB	F = with analog interface	
1000 = 100kW	2250 = 2250V	2000 = 2000A	R = LAN, USB + CAN + RS485		

1.5 Specification sheet

General specification	
Voltage rise slew rate	
Maximum slew rate	6000V/s
Voltage fall time	
No load	<2s
Full load	≤30ms
Transient response	With 10%~90% dynamic load change, it takes less than 2ms for the equipment voltage to recover to 75% accuracy range of the rated value
Parallel	It supports 10 master and slave parallel machines of the same model
Protection	OVP, OCP, OPP, OTP, LVP etc..
Interface	Standard LAN、USB(serial) (optional GPIB、CAN、RS485&RS232)
Protocol	SCPI、MODBUS、CAN-Open protocols
Input characteristics	
Input voltage	340VAC~460VAC, 47Hz~63Hz
Power factor	0.99 (Typical)
Efficiency	>93% (Typical)
Operation environment	
Working temp	0℃~40℃
Storage temp	-20℃~70℃
Altitude	<2000m
Cooling	Air cooling, intelligent fan control

Specification table 1

Model	FTP9050-80-170	FTP9050-200-70	FTP9050-400-40	FTP9050-500-30	FTP9050-800-25
Voltage	0~80V	0~200V	0~400V	0~500V	0~800V
Current	0~170A	0~70A	0~40A	0~30A	0~25A
Power	0~5kW				
Model	FTP9100-80-340	FTP9100-200-140	FTP9100-400-80	FTP9100-500-60	FTP9100-800-50
Voltage	0~80V	0~200V	0~400V	0~500V	0~800V
Current	0~340A	0~140A	0~80A	0~60A	0~50A
Power	0~10kW				
Model	FTP9150-80-510	FTP9150-200-210	FTP9150-400-120	FTP9150-500-90	FTP9150-800-75
Voltage	0~80V	0~200V	0~400V	0~500V	0~800V
Current	0~510A	0~210A	0~120A	0~90A	0~75A
Power	0~15kW				
Model	FTP9300-80-1020	FTP9300-200-420	FTP9300-400-240	FTP9300-500-180	FTP9300-800-150
Voltage	0~80V	0~200V	0~400V	0~500V	0~800V
Current	0~1020A	0~420A	0~240A	0~180A	0~150A
Power	0~30kW				
Model	FTP9600-80-2040	FTP9600-200-840	FTP9600-400-480	FTP9600-500-360	FTP9600-800-300
Voltage	0~80V	0~200V	0~400V	0~500V	0~800V

Current	0~2040 A	0~840A	0~480A	0~360A	0~300A	
Power	0~60kW					
Model	FTP9900-80-3060	FTP9900-200-1260	FTP9900-400-720	FTP9900-500-540	FTP9900-800-450	
Voltage	0~80V	0~200V	0~400V	0~500V	0~800V	
Current	0~3060 A	0~1260A	0~720A	0~540A	0~450A	
Power	0~90kW					
Model	~	FTP91200-200-1680	FTP91200-400-960	FTP91200-500-720	FTP91200-800-600	
Voltage	~	0~200V	0~400V	0~500V	0~800V	
Current	~	0~1680A	0~960A	0~720A	0~600A	
Power	0~120kW					
Voltage programming①						
Resolution	16bits					
Accuracy	0.02%+0.02%F.S.					
Current programming①						
Resolution	16bits					
Accuracy	0.1%+0.1% F.S.					
Power programming①						
Accuracy	1%F.S.					
External analog programming①						
Control voltage	0~5V corresponds to 0~100%F.S.					
Voltage accuracy	0.5%F.S.					
Current accuracy	0.5%F.S.					
Line regulation②						
Voltage	0.02%F.S.					
Current	0.05%F.S.					
Power	0.05%F.S.					
Load regulation③						
Voltage	0.05%F.S.					
Current	0.15%F.S.					
Power	0.75%F.S.					
Voltage measurement①						
Resolution	16bits					
Accuracy	0.02%+0.02%F.S.					
Current measurement①						
Resolution	16Bits					
Accuracy	0.1%+0.1% F.S.					
Power measurement①						
Accuracy	1%F.S.					
Ripple noise④						
Ripple Vpp	5kW	160mV	300mV	550mV	450mV	800mV
	10kW	320mV	300mV	550mV	450mV	800mV
	15kW	320mV	300mV	550mV	450mV	800mV
Ripple Vrms	5kW	16mV	40mV	65mV	70mV	200mV
	10kW	25mV	40mV	65mV	70mV	200mV
	15kW	25mV	40mV	65mV	70mV	200mV

Size (W x H x D)	5kW~15kW: 482.6mm x 132.5mm x 702.0mm, includes output protection cover
	20kW~30kW: 482.6mm x 266mm x 738.0mm, includes protection cover, excludes casters
Weight	5kW≈17kg, 10kW≈24kg, 15kW≈30kg, 30kW≈65kg

Specification table 2

Model	FTP9100-1000-30	-	FTP9100-1500-25	-
Voltage	0~1000V	-	0~1500V	-
Current	0~30A	-	0~25A	-
Power	0~10kW			
Model	FTP9150-1000-40	FTP9150-1200-40	FTP9150-1500-30	FTP9150-2250-25
Voltage	0~1000V	0~1200V	0~1500V	0~2250V
Current	0~40A	0~40A	0~30A	0~25A
Power	0~15kW			
Model	FTP9200-1000-60	-	FTP9200-1500-50	
Voltage	0~1000V	-	0~1500V	
Current	0~60A	-	0~50A	
Power	0~20kW			
Model	FTP9300-1000-80	FTP9300-1200-80	FTP9300-1500-60	FTP9300-2250-50
Voltage	0~1000V	0~1200V	0~1500V	0~2250V
Current	0~80A	0~80A	0~60A	0~50A
Power	0~30kW			
Model	FTP9400-1000-120	-	FTP9400-1500-100	-
Voltage	0~1000V	-	0~1500V	-
Current	0~120A	-	0~100A	-
Power	0~40kW			
Model	FTP9600-1000-180	FTP9600-1200-160	FTP9600-1500-120	FTP9600-2250-100
Voltage	0~1000V	0~1200V	0~1500V	0~2250V
Current	0~180A	0~160A	0~120A	0~100A
Power	0~60kW			
Model	FTP9800-1000-240	FTP9900-1200-240	FTP9900-1500-180	FTP9900-2250-150
Voltage	0~1000V	0~1200V	0~1500V	0~2250V
Current	0~240A	0~240A	0~180A	0~150A
Power	0~80kW	0~90kW		
Model	FTP91000-1000-300	FTP91200-1200-320	FTP91200-1500-240	FTP91200-2250-200
Voltage	0~1000V	0~1200V	0~1500V	0~2250V
Current	0~300A	0~320A	0~240A	0~200A
Power	0~100kW	0~120kW		
Voltage programming①				
Resolution	16bits			
Accuracy	0.02%+0.02%F.S.			
Power programming①				
Resolution	16bits			
Accuracy	0.1%+0.1% F.S.			
Power programming①				
Accuracy	1%F.S.			

External analog programming①					
Control voltage		0~10V corresponds to 0~100%F.S.			
Voltage accuracy		0.5%F.S.			
Current accuracy		0.5%F.S.			
Line regulation②					
Voltage		0.02%F.S.			
Current		0.05%F.S.			
Power		0.05%F.S.			
Load regulation③					
Voltage		0.05%F.S.			
Current		0.15%F.S.			
Power		0.75%F.S.			
Voltage measurement①					
Resolution		16bits			
Accuracy		0.02%+0.02%F.S.			
Current measurement①					
Resolution		16Bits			
Accuracy		0.1%+0.1% F.S.			
Power measurement①					
Accuracy		1%F.S.			
Ripple noise④					
Ripple Vpp	10kW	1600mV		-	-
	15kW	2000mV	2000mV	2400mV	3600mV
Ripple Vrms	10kW	350mV		-	-
	15kW	350mV	350mV	400mV	400mV
Size（W x H x D）		5kW~15kW: 482.6mm x 132.5mm x 702.0mm, includes output protection cover			
		20kW~30kW: 482.6mm x 266mm x 738.0mm, includes protection cover, excludes casters			
Weight		5kW≈17kg, 10kW≈24kg, 15kW≈30kg, 30kW≈65kg			

Table 1- 3 Specification 3

Model	FTP9060-300-75	FTP9060-500-40	FTP9060-800-25	-	-	-
Voltage	0~300V	0~500V	0~800V	-	-	-
Current	0~75A	0~40A	0~25A	-	-	-
Power	0~6kW					
Model	FTP9120-300-150	FTP9120-500-80	FTP9120-800-50	FTP9120-1000-40	FTP9120-1500-25	-
Voltage	0~300V	0~500V	0~800V	0~1000V	0~1500V	-
Current	0~150A	0~80A	0~50A	0~40A	0~25A	-
Power	0~12kW					
Model	FTP9180-300-225	FTP9180-500-120	FTP9180-800-75	-	FTP9180-1500-40	FTP9180-2250-25
Voltage	0~300V	0~500V	0~800V	-	0~1500V	0~2250V
Current	0~225A	0~120A	0~75A	-	0~40A	0~25A
Power	0~18kW					
Model	FTP9240-300-300	FTP9240-500-160	FTP9240-800-100	FTP9240-1000-80	FTP9240-1500-50	-
Voltage	0~300V	0~500V	0~800V	0~1000V	0~1500V	-

Current	0~300A	0~160A	0~100A	0~80A	0~50A	-
Power	0~24kW					
Model	FTP9360-300-450	FTP9360-500-240	FTP9360-800-150	FTP9360-1000-120	FTP9360-1500-80	FTP9360-2250-50
Voltage	0~300V	0~500V	0~800V	0~1000V	0~1500V	0~2250V
Current	0~450A	0~240A	0~150A	0~120A	0~80A	0~50A
Power	0~36kW					
Model	FTP9720-300-900	FTP9720-500-480	FTP9720-800-300	FTP9720-1000-240	FTP9720-1500-160	FTP9720-2250-100
Voltage	0~300V	0~500V	0~800V	0~1000V	0~1500V	0~2250V
Current	0~900A	0~480A	0~300A	0~240A	0~160A	0~100A
Power	0~72kW					
Model	FTP9900-300-1125	FTP9900-500-600	FTP9900-800-375	FTP9720-1000-240	FTP9900-1500-200	FTP9900-2250-125
Voltage	0~300V	0~500V	0~800V	0~1000V	0~1500V	0~2250V
Current	0~1125A	0~600A	0~375A	0~240A	0~200A	0~125A
Power	0~90kW					
Model	FTP91080-300-1350	FTP91080-500-720	FTP91080-800-450	FTP91080-1000-360	FTP91080-1500-200	FTP91080-2250-150
Voltage	0~300V	0~500V	0~800V	0~1000V	0~1500V	0~2250V
Current	0~1350A	0~720A	0~450A	0~360A	0~240A	0~150A
Power	0~108kW					
Voltage programming①						
Resolution	16bits					
Accuracy	0.02%+0.02%F.S.					
Current programming①						
Resolution	16bits					
Accuracy	0.1%+0.1% F.S.					
Power programming①						
Accuracy	1%F.S.					
External analog programming①						
Control voltage	0~5V 对应 0~100%F.S.					
Voltage accuracy	0.5%F.S.					
Current accuracy	0.5%F.S.					
Line regulation②						
Voltage	0.02%F.S.					
Current	0.05%F.S.					
Power	0.05%F.S.					
Load regulation③						
Voltage	0.05%F.S.					
Current	0.15%F.S.					
Power	0.75%F.S.					
Voltage measurement①						

Resolution	16bits					
Accuracy	0.02%+0.02%F.S.					
Current measurement①						
Resolution	16Bits					
Accuracy	0.1%+0.1% F.S.					
Power measurement①						
Accuracy	1%F.S.					
Ripple& noise④						
Voltage ripple p-p	300mV	450 mV	800 mV	2000mV	2400mV	3600mV
Voltage ripple rms	40mV	70 mV	200mV	350mV	400mV	400mV
Size (WxHxD)	6kW~18kW: 482.6mm x 132.5mm x 707.0mm, includes output protection cover					
	24kW~36kW: 482.6mm x 266mm x 743.0mm, includes protection cover, excludes casters					
Weight	6kW≈17kg, 12kW≈24kg, 18kW≈30kg, 36kW≈65kg					

Notice:

- ①精度测定条件: 25℃±5℃
- ②线性调整率测定条件: 输入电压变化±10%
- ③电压、电流负载调整率测定条件: 负载变化 0~100%; 功率负载调整率测定条件: 电压、电流变化 10%~90%
- ④纹波测定条件: 电压测定带宽 0~20MHz; 示波器测试端口需并接 10uF、0.1uF 电容。

2. Quick Guide

2.1 Checking Goods

Upon reception of the power supply, please examine the equipment according to procedures stipulated as below.

(1) Check if there is damage during transportation.

Contact authorized dealer or Faithtech after-sale service immediately if the packing or protective cushion is severely damaged.



Do not return the instrument without obtaining prior approval from Faithtech.

(2) Check for the accessories.

Make sure you have received the following accessories along with the power supply:

Table 2-1 Accessories Explanation

Accessory	QTY	Explanation
Protective cover	1 Set	Input and output protection
2PIN 5.08mm terminal	1 PCS	Voltage remote sense connection terminal
2PIN 2.54mm terminal	1 PCS	Master-Slave parallel connection terminal
USB communication cable	1 PCS	For connecting PC and USB port
LAN communication cable	1 PCS	For connection PC and LAN port
User Manual	1 PCS	Installing and operation info
CD Disk	1 PCS	Software and tech info
Warranty & QC PASS Card	1 PCS	Warranty and after-sale info

Contact authorized dealer or Faithtech after-sale service immediately if there is damage or miss.

(3) Check for the power supply unit.

Contact authorized dealer or Faithtech after-sale service immediately if the power supply case is damaged or working abnormally.


(4) Cleaning.

If you need to clean the casing of the machine, please wipe it gently with a dry cloth or a slightly damp cloth. Do not wipe the inside of the machine.



WARNING Turn off the power supply before cleaning.

2.2 Front Panel



- ① Power switch
- ② TFT color screen
- ③ Keyboard
- ④ Rotary knob

2.3 Keyboard



















Figure 2-2 FTP9000 keyboard

Table 2-2 Key Function Descriptions

Button	Key Name	Description
	Voltage Setting Key	Switch to output setting mode from other functions, and Voltage is now settable;
	Current Setting Key	Switch to output setting mode from other functions, and Current is now settable;
	Power Setting Key	Switch to output setting mode from other functions, and Power is now settable;

	Advanced Test Key	For performing Sequence Test, Voltage RAMP, RESI internal resistance simulation, etc.
	SAVE Key	Save the settings of the static output to internal memory.
	Recall Key	Recall the saved settings from internal memory.
	Protection Clear Key	Clear the occurred protection and warning messages.
	Main Menu Key	Enter the main menu.
	Compound Function Key	Work with other key together
	Lock or unlock the keyboard	In locked state, only  and  are valid.
	Numeric and Decimal Point	Enter digital data.
	Clear Key	Each press clears one digit of your numeric input.
	Cursor Movement Keys	Control the cursor to move between digits when setting parameters. In menu navigation, used for selecting the specified item.
	ENTER Key	Enter set item, or confirm input and exit set item.
	EXIT Key	Exit set item or current menu.
	Output On/Off Key	Turn on/off power supply output.

2.4 Screen Display




Figure 2-3 MAIN PAGE Display

- ① Specification info of the power supply;
- ② Readback voltage, current, etc. parameters display area;
- ③ Status prompt area;
- ④ Parameters setting area;

About specification info:

Displays the rated voltage, rated current, rated power of the power supply;

About V, I parameters display area:

Displays readback voltage, current, power, measurement result etc.. However, the actual displayed information varies, for example, in V.I.P static output mode, the area displays output voltage, current and power; in sequence test mode, the area displays output voltage, current, sequence current steps and sequence cycle times.

About Status prompt area:

Sense V-Sense: Blank (local sensing), Sense (remote sensing);

PMF Protection occurred: Blank (no protection occurred), PMF, OVP, OCP, OPP, OTP1, OTP2, LVP, OP, OC, OV, RVP, CMF etc.. protections occurred;

Σ-P Parallel operation;

E-VIP External programming: Blank (Analog programming is off), E-VIP;

Off Output mode indicator: CV, CC, CP, Off;

2.5 Rear Panel




Figure 2-4 FTP9000 Rear Panel

Item	Name	Description
1	Share	Master-Slave parallel ports
2	V SENSE	This connector compensates for any voltage drop generated by the cable resistance. Be sure to connect the remote sense connector "+" to the positive output terminal and the "-" connector to the negative output terminal. Do not reverse the connections.
3	"+", "-" Output	The output terminals of the DC Power Supply.
4	GPIB (or CAN + RS485)	The remote controller uses the GPIB connector to connect to a PC for remote operation.
5	LAN, USB	The remote controller uses the USB/LAN connector to connect to a PC for remote operation.
6	PRO-INT	This interface has the functions of analog programming input, voltage/current monitoring output, external control, power supply status and work mode indication. Refer to "2.7.5 PRO-INT Analog Interface" for details.
7	AC INPUT	L1、L2、L3、PE three phase AC INPUT

2.6 Installing

2.6.1 Preparation For Use

- (1) Insure the Power Supply is connected to the AC line input that meets the specification.
- (2) The instrument must be installed in an area with good air circulation to avoid the internal temperature getting too high.
- (3) For indoor use only, ambient temperature 0°C to 40°C.

2.6.2 Requirements of Input Power

Please pay attention to the following items for FTP9000 series power supply input connection:

- ① Three-phase input: 340VAC~460VAC, 47~63Hz;
- ② Ensure reliable grounding;
- ③ 5kW model power supply is connected to L1, L2 and grounding terminal, other types of power supply need to be connected to L1, L2, L3 and grounding terminal;
- ④ Please refer to "Table 6-1 Recommended Wire Diameters for Cables" for the selection of input wire diameters to avoid potential safety hazards due to thinner wire diameters.



1. To protect the operator, the wire connected to the GND terminal must be connected to the earth. Under no circumstances shall this DC Power Supply be operated without an adequate ground connection.
2. Installation of the power cord must be done by a professional and compliant with local electrical codes.

2.6.3 Power ON Self Check

When powered on, the power supply will conduct self check, the check process and results will be displayed on the screen, such as below:

(c)All rights reserved.

Test PRI Fault. OK

Loading calibration data. OK

Test sample. OK

Loading parameters. OK

Figure 2-5 FTP9000 Power ON Self Check

The power supply will enter MAIN PAGE if all checking results are OK, otherwise it will wait for 5 seconds before entering the MAIN PAGE.



CAUTION

For fault meaning please refer to "Table 5-2 Power On Fault Check".

2.7 Connection

2.7.1 Input Connection

The user connects the three-phase wire and the ground wire to the power supply input terminal as shown in Figure 2-6. For the size of the wire diameter, please refer to "Table 6-1 Recommended Wire Diameter for Cables".




Figure 2-6 Power supply Input Connection



1. To protect the operator, the wire connected to the GND terminal must be connected to the earth. Under no circumstances shall this DC Power Supply be operated without an adequate ground connection.
2. Installation of the power cord must be done by a professional and compliant with local electrical codes.

2.7.2 Input Connection for Multiple Power Supplies

If multiple 5kW or 10kW models are connected to the grid, it is recommended to distribute the access points in a balanced manner as shown in the figure below. When the 15kW model is connected to the three-phase power grid, there is no need to consider the imbalance of the power grid.




Figure 2-7 Input Connection of multiple 5kW Models




Figure 2-8 Input Connection of multiple 10kW Models

2.7.3 Output Connection

The device under test is connected to the “+” and “-” output terminals on the rear panel of the power supply. When connecting, pay attention to the wire diameter, length and polarity of the output cable. To prevent the wire diameter from being too small to affect the test accuracy and generate large heat to cause safety accidents, please refer to "Table 6-1 Recommended Wire Diameters for Cables" for wire diameter selection.




Figure 2-9 Power Supply Output Connection




CAUTION

The diameter of the wire connected to the load must be adequate so as to carry the maximum applied current.

2.7.4 Remote Sensing Connection

FTP9000 series power supplies are able to compensate for the voltage drop caused by output connecting cables. Use two wires to connect the positive/negative connectors of the load to the corresponding positive/negative remote sensing connector on the rear panel, symbol "Sense" will be prompted in the status prompt area of the screen if the power supply output is turned on.



1. It is OK to choose red and black wires with a cross-sectional area of 0.5mm^2 to 1mm^2 for voltage compensation wire, try double strand the wire as much as possible.



CAUTION

2. The 80V type of FTP9000 series power supply has a compensation voltage drop of less than 1.5V, and other voltage models have a compensation voltage drop of less than 5V. For special requirements, please consult the dealer or the Faithtech Technology Department.

2.7.5 PRO-INT Analog Interface

FTP9000 series power supply provides optional PRO-INT analog Interface at its rear panel. This interface has the functions of analog programming input, voltage/current monitoring output, external control, power supply status and work mode indication.




Figure 2-11 PRO-INT Analog Interface

Table 2-4 Analog Interface Function Description

PIN No.	PIN Name	I/O	Description
1	Ready	Output	Power supply status indicating, 5V TTL, H: fault, L: normal
2	MODE	Output	Power supply output mode indicating, 5V TTL, H: CC or CP, L: CV
3	INHIBIT	Input	External control port, 5V TTL, low level or falling edge effective, can be set to Trigger, Toggle, Hold three behaviors. Refer to “3.7.2 External Control”
4	DGND	-	Digital ground
5	DGND	-	Digital ground
6	AGND	-	Analog ground
7	VMON	Output	Output Voltage monitoring port, monitoring output range 0~5VDC corresponds to 0~100%F.S. rated voltage of the power supply output
8	IMON	Output	Output current monitoring port, monitoring output range 0~5VDC corresponds to 0~100%F.S. rated current of the power supply output
9	I-SET	Input	Analog programming current input port, input range 0~5VDC or optional 0~20mA corresponds to 0~100%F.S. rated current of the power supply output
10	AGND	-	Analog ground
11	V-SET	Input	Analog programming voltage input port, input range 0~5VDC or optional 0~20mA corresponds to 0~100%F.S. rated voltage of the power supply output
12	P-SET	Input	Analog programming power input port, input range 0~5VDC or optional 0~20mA corresponds to 0~100%F.S. rated power of the power supply output
13, 14	RS485-A	-	Communication port for master-slave parallel operation
15, 16	RS485-B	-	Communication port for master-slave parallel operation

3. Function Introduction

This chapter describes the main functions and characteristics of the power supply. Reading this chapter, you will have a deeper understanding of FTP9000 series power supplies.

3.1 Local & remote operation mode

The power supply provides two operation modes: local operation and remote operation. In the local operation mode, the user mainly operates through the keyboard and knob on the front panel, and checks the power status through the LCD display; in the remote operation mode, the user mainly performs settings and operations via the communication interface and programming commands.

Local operation mode

When the power supply is turned on, it operates in local operation mode by default. In this mode, the user operates the power supply through the front panel keyboard. The LCD screen provides users with display functions such as parameter viewing, measurement display and status indication.

Some parameters can only be set in local mode, including:

- * System language
- * Serial port baud rate and parity method
- * Key sound
- * IP address and subnet mask
- * Communication protocol selection

Remote operation mode

To enter the remote operation mode, please use the proper communication cable to connect the PC with the power supply. The communication configuration parameters must be consistent with the control device settings. Upon receiving the programming command, the power supply automatically switches to the remote operation mode from local control mode.

In remote control mode, the power supply can only be controlled by programming commands. Press “Enter” to return to local operation mode.

3.2 Menu Layout

3.2.1 Set Menu



Press  to enter main menu, then select “Set” and press  to pop up sub menu as below:

Table 3-1 Set Menu Layout

App Set	Samp Rate	Data transmission speed, choices: 1000Hz/500Hz/200Hz/100Hz/10Hz, default value 10Hz
	Prio SLT	Choice for CV or CC priority. Default value: Volt (CV Priority)
	V _{slew-UP}	Voltage rise slew rate, range: 0.0006V/s~6000V/s, default value: 50% of max value
	V _{slew-DN}	Voltage fall slew rate, range: 0.0006V/s~6000V/s, default value: 50% of max value
	I _{slew-UP}	Current rise slew rate, range: 0.0006A/s~2000A/s, default value: max value
	I _{slew-DN}	Current fall slew rate, range: 0.0006A/s~2000A/s, default value: max value
Protect	OVP	Set overvoltage protection point, set 0 to turn off this protection.
	OCP	Set overcurrent protection point, set 0 to turn off this protection.
	OPP	Set overpower protection point, set 0 to turn off this protection.
	LVP	Set low voltage protection point, set 0 to turn off this protection.
	Over time	Set communication error time out, range: 0.0~60.0s, set 0 to turn off this protection;
	Detect RV	Turn on/off reverse voltage protection, default value: Closed
Limit	V_MAX	Upper limit of static output voltage set , default max output voltage
	V_MIN	Lower limit of static output voltage set, default 0 means no limit
	I_MAX	Upper limit of static output current set, default max output current
	I_MIN	Lower limit of static output current set, default 0 means no limit
	P_MAX	Upper limit of static output power set, default max output power
	P_MIN	Lower limit of static output power set, default 0 means no limit
Ext Prog	APG_V	Turn on/off external voltage programming, default: OFF.
	APG_I	Turn on/off external current programming, default: OFF.
	APG_P	Turn on/off external power programming, default: OFF.
	EXT-S	Set external input signal behavior, choices: Trigger/Toggle/Hold; default value: Trigger (Refer to 3.7.2 External Control)
	Vref	reference voltage for external programming or monitoring, choose 5V or 10V
Parallel	M_or_S	Set the power supply as master or slave, default value: master
	S.NUM	Set number of slaves in master, range: 1~9
	MS_CTRL	Turn on/off parallel function, default value: OFF

3.2.2 System Menu



Press  to enter main menu, then select “System” and press  to pop up sub menu as below:

Table 3-2 System Menu Layout

Communication	IP	Default 192.168.1.123
	S-Mask	Default 255.255.255.0
	Baud	Serial port baud rate, 4800/9600/19200/38400/115200, default: 9600.
	Parity	no parity/odd parity/even parity, default: no parity.
	DEVI-ADDR	Device address in MODBUS protocol, range 0~254, default: 160
	GPIB	set GPIB address, range: 0~30, default: 5.
	Protocol	SCPI/MODBUS, default: MODBUS
Factory		Reset to factory setting. Reboot the machine to take effect.
Others	Language	Simplified Chinese/Traditional Chinese/English. Default: English.
	Sound	Keyboard sound ON/OFF. Default: ON
	Power Save	Power down save function ON/OFF. Default: ON
	Shortcut	Fast recall function ON/OFF. Default: OFF

3.2.3 Edit Menu





Press  to enter main menu, then select “Edit” and press  to pop up sub menu as below:

Table 3-3 Edit Menu Layout




Edit	Sequence	Select sequence file number, range 1~10
	Back	Exit

3.2.4 About Menu

Press  to enter main menu, then select “About” and press  to pop up sub menu such as HMI, MAIN, COMM program version information etc..

3.3 Static Output Function

FTP9000 series power supply provides auto ranging wide range output within its rated power. The output range is 0 ~ 102% rated output of voltage, current and power.

Press ,  or , the power supply enters static output function, the screen displays information as below:













Figure 3-1 Static Output View

Setting output voltage:

1. Press , power supply enters static output mode, the cursor for voltage set blinks, also you can rotate

the knob to highlight the voltage setting and press  to edit voltage,

2. Use  至  与  to set the value and press  to confirm the voltage setting or rotate the  knob to set the value.

When using the “Rotary” knob  for setting, use  与  to move the cursor to the individual digit, and then rotate the rotary knob to increase or decrease the value.

When power supply is reset to factory setting, the default voltage set is 0V.

Setting output current or output power:

Press  or  and follow the similar steps.

When power supply is reset to factory setting, the default set current is maximum output current, default set power is maximum output power.

3.3.1 Power supply output modes

FTP9000 series power supply has three output modes: CV (constant voltage mode), CC (constant current mode), CP (constant power mode).

The power supply generally outputs voltage according to the set value, in such situation, "CV" is displayed in status prompt area. When the output current exceeds the set current value, the power supply will automatically switch to CC mode, the output current can be changed by setting the output current value, in this situation "CC" is displayed in status prompt area. When the output power exceeds the set power value, the power supply automatically switch to CP mode, in which the output power can be changed by setting the output power value, in this situation, "CP" is displayed in status prompt area.


3.3.2 Limit Voltage/Current/Power Set

FTP9000 series power supply allows for setting upper and lower limits on voltage, current and power. When the upper and lower limit is set to non-zero, the setting range of static output voltage, current, and power parameters is limited between the upper and lower limit. If the input exceeds the limit, it will be invalid. This function is useful for preventing misoperation from damaging the user's equipment.

The limit function will be canceled if upper and lower limit both are set to 0.

Operation:

1. Press  ;

2. Select "Set" >> "Limit", press  to enter the limit setting page shown as below:

Set	System	Edit	About
V_MAX	0.000	V	
V_MIN	0.000	V	
I_MAX	0.000	A	
I_MIN	0.000	A	
P_MAX	0.000	W	
P_MIN	0.000	W	



Figure 3-2 Voltage, Current, Power Limit Set

3. Select the desired item and set the corresponding parameter.

3.4 Voltage Slew Rate And Current Slew Rate

FTP9000 series power supply supports adjustable voltage and current slew rate, which effectively avoids the inrush damage or surge damage to the units under test.

Operation:

1. Press  ;
2. Select "Set" >> "App Set", press  to enter the application setting page shown as below:

Set	System	Edit	About
Samp Rate	10Hz		
Prio SLT	Volt		
$V_{\text{slew-UP}}$	5000.0	V/s	
$V_{\text{slew-DN}}$	5000.0	V/s	
$I_{\text{slew-UP}}$	2000.0	V/s	
$I_{\text{slew-DN}}$	2000.0	V/s	

Figure 3-3 Voltage, Current Slew Rate Set

3. Select parameters to set corresponding value.

3.5 CV/CC Priority Start function

FTP9000 series power supply provides CC priority and CV priority start function, which forces the power supply to operate in CC or CV mode at the moment the output is turned on, effectively avoids the current or voltage overshoot resulted from capacitive or inductive load.





Figure 3-4 CV, CC Priority V / I Waveform

Operation:

1. Press  ;
2. Select "Set" >> "App Set", press "Enter" to enter the application setting page shown as below:

Set	System	Edit	About
Samp Rate	10Hz		
Prio SLT	Volt		
V _{slew-UP}	5000.0	V/s	
V _{slew-DN}	5000.0	V/s	
I _{slew-UP}	2000.0	V/s	
I _{slew-DN}	2000.0	V/s	



Figure 3-5 CV, CC Priority Set

3. Select "Prio SLT" item to set, "Volt" stands for voltage priority while "Curr" stands for current priority.

3.6 Output Control

The power supply's output is turned off when it is switched on. Users control its output via front panel key.



-  key is lighted, suggests the output is turned on, the screen displays voltage, current, power, operation mode in real time;
-  key is light off, suggests the output is turned off, "OFF" is displayed in the status prompt area.

3.7 Analog interface (optional PRO-INT interface)

3.7.1 Analog Programming

Users are able to control the power supply's output voltage, output current and output power through external 0...5VDC or 0...10VDC voltage, connections as follows:




Figure 3-6 Analog Interface Programming Connection

Analog programming control speed is 1000 points per second, external 0...5VDC or 0...10VDC voltage corresponds to 0 ~ 100%F.S. output voltage, current, power.





Figure 3-7 Input Programming Signal And Output Relation

Operation:

1. Press  to enter the main menu.

2. Select "Set" >> "EXT Prog" and press  to enter external programming page as shown below:

Set	System	Edit	About
APG_V	OFF		
APG_I	OFF		
APG_P	OFF		
EXT-S	Trigger		
Vref	0-5V		

Figure 3-8 External Programming Set

3. Select APG_V, APG_I, APG_P for performing voltage programming, current programming or power programming turn on/off operations respectively, the status prompt area will prompt "E-VIP" symbol if any of these three programming selections is turned on.

4. Press  to turn on output.

1. Altering of "External Programming Set" is allowed only when the output is turned off.

2. The external signal controls the output voltage/current/power on the condition that corresponds voltage/current/power programming is turned on, otherwise the power supply output can still be controlled by the front panel or remote communication.



Notice

3.7.2 External Control

FTP9000 series power supply analog interface provides an input “INHIBIT” for trigger signal, as shown below:




Figure 3-9 Trigger Signal Connection

This “INHIBIT” port receives 5V TTL level signal, low level is effective. You can use a physical switch such as "Figure 3-9 Trigger Signal Connection" or a 0~5VDC signal source for triggering. Closed or 0V is low level, open or 5V is high level. The port response time is about 20 milliseconds, and can be set to Trigger, Toggle, Hold three behaviors.

Trigger: Default setting. Used as trigger signal. The port detects a valid low-level pulse, that is, a trigger signal is received.



Toggle: Used as power supply output ON/OFF control signal. The output ON/OFF is switched once when the port detects a valid low-level pulse. Same effect as you press  once on the front panel.

Hold: Used as power supply output ON/OFF control signal. Output is turned ON when the port detects a valid low-level signal; turned off when the port detects a valid high-level signal.



Keyboard control, external control and System Bus control take effect at the same time and work together.

Operation:

1. Press  to enter the main menu.
2. Select “SET” >> “Ext Prog” and press  to enter external programming page as shown in Figure 3-8.
3. Select “EXT-S”, you can configure among “Trigger”, “Toggle”, or “Hold”. Default setting is “Trigger”.

3.7.3 Voltage, Current Monitoring Output

FTP9000 series power supply provides analog monitoring output function for its output voltage and current, with a speed up to 1000 points per second. Power supply 0 ~ 100%F.S. output voltage/current corresponds to 0...5VDC or 0...10VDC monitoring output, this function is valid once the power supply is powered on.




Figure 3-10 Voltage, Current Analog Monitoring Connection




Figure 3-11 Output Voltage, Current And Monitoring Output

3.7.4 Output Mode & Status Monitoring

The FTP9000 series power supply has an output mode signal port and a fault indication signal port. The port outputs a 5V TTL level signal, and its functions are as follows:

Output mode signal port, low level indicates that the power supply is working in CV mode, and high level indicates that the power supply is working in CC or CP mode;



Fault indication signal port, low level indicates that the power supply is working normally, high level indicates that the power supply is abnormal, or protection has occurred but not cleared.

For specific please refer "Table 2-4 Analog Interface Function Explanation".

3.8 Protection


FTP9000 series power supply provides protections against overvoltage, overcurrent, overpower, low voltage, output reverse voltage, communication timed out, overtemperature.

When a protection occurs, the power supply will turn off output, sounds an alarm, and prompt corresponding protection information on display.

1. Press  to enter the main menu.
2. Select "Set" >> "Protect" and press  to enter protection setting page as shown below:

Set	System	Edit	About
OVP	0.000 V		
OCP	0.000 A		
OPP	0.000 W		
LVP	0.000 V		
Over time	0.0 s		
Detect RV	OFF		

Figure 3-12 Protection Set

3. Select the corresponding item to set the desired value.
4. When a protection occurred, press  to clear the protection state and warning message.

Overvoltage protection (OV/OVP)

It has two kinds of overvoltage protection: hardware overvoltage (OV) and software overvoltage (OVP).

Hardware overvoltage protection (OV): It is triggered once the output voltage exceeds 105% rated output voltage, and "OV" is prompt on display.

Software overvoltage protection (OVP): It is programmable as shown in "Figure 3-12 Protection Set". Users are able to set the OVP threshold, set to 0 means to turn off OVP. OVP is triggered once the output voltage exceeds OVP set, and "OVP" is prompt on display.

Overcurrent protection (OC/OCP)

It has two kinds of overcurrent protection: hardware overcurrent (OC) and software overcurrent (OCP).

Hardware overcurrent protection (OC): It is triggered once the output current exceeds 105% rated output current, and "OC" is prompt on display.

Software overcurrent protection (OCP): It is programmable as shown in "Figure 3-12 Protection Set". Users are able to set the OCP threshold, set to 0 means to turn off OCP. OCP is triggered once the output current exceeds OCP set, and "OCP" is prompt on display.

Overpower protection (OP/OPP)

It has two kinds of overpower protection: hardware overpower (OP) and software overpower (OPP).

Hardware overpower protection (OP): It is triggered once the output power exceeds 110% rated output power, and “OP” is prompt on display.

Software overpower protection (OPP): It is programmable as shown in “Figure 3-12 Protection Set”. Users are able to set the OPP threshold, set to 0 means to turn off OPP. OPP is triggered once the output power exceeds OPP set, and “OPP” is prompt on display.

Low voltage protection (LVP)

It is programmable as shown in “Figure 3-12 Protection Set”. Users are able to set the low voltage protection threshold, set to 0 means to turn off this protection. Low voltage protection is triggered once the output voltage is below the set value, and “LVP” is prompt on display.

Reverse voltage warning (RVP)

It is triggered once the output polarities are reverse connected, and “RVP” is prompt on display.

Communication timed out protection (CMF)

When power supply is controlled remotely, you can turn on this protection. It is triggered if the host computer did not send communication command to the power supply for a certain period, the power supply output will be turned off and “CMF” is prompt on display. The triggering time can be set as in “Figure 3-12 Protection Set”, range 0.0 ~ 60.0 seconds.

Overtemperature protection

It is triggered once the temperature of inner power components exceeds allowed temperature range, “OTP1” or “OTP2” is prompt on display.

3.9 Save And Recall


The power supply provides 20 groups of storage locations for users to save static output parameters, such as voltage setting, current setting, power setting, voltage slope, and current slope to a designated internal memory location, so that the user can easily and quickly recall and use. If the shortcut function is turned on, you only need to press a number key to recall the saved parameters. This function can significantly reduce user's operations and improve test efficiency.

Operation:

When users need to use the save and recall functions, they should first configure the parameters of the static output. The following examples illustrate:


1. Switch to the static output (by pressing the V-Set, I-Set or P-Set button), set the voltage to 12V, the current to 10A, the power to 1000W, the maximum voltage slope, and the maximum current slope;

2. Press  to enter save state;


3. Input number “1” and press  to validate the setting, so the setting parameters now stored to position “1”;

4. Change the static output parameters, set the voltage to 24V, the current to 20A, the power to 2000W, the maximum voltage slope, and the maximum current slope;


5. Press  to enter save state;

6. Input number “2” and press  to validate the setting, the setting parameters now stored to position “2”;

7. Press  to enter recall interface;

8. Input number “1” and press  to activated it, the power supply will switch to static output with the recalled parameters of position “1”: voltage 12V, current 10A, power 1000W, maximum voltage and current slew rate;

9. Press  to enter recall interface;

10. Input number “2” and press  to activated it, the power supply will switch to static output with the recalled parameters of position “2”: voltage 24V, current 20A, power 2000W, maximum voltage and current slew rate;

Shortcut Function


1. Press  ;

2. Select “Set” >> “System” and press  , then select “Others” and press  again;

3. Set “Shortcut” as ON, so as to activate it;

4. Press  to return to MAIN PAGE;

5. In MAIN PAGE, when it is not in parameter editing state, press number key to quick recall parameters in

position 1~10.  ~  corresponds to storage location 1 ~ 9,  corresponds to position 10.

3.10 Power-down Save

FTP9000 series provides power-down save function. The power supply will resume last time working parameters at its power on moment when power-down save function is activated, otherwise the power supply will initialize using default parameters when it is turned on.

1. Press  ;



2. Select “Set” >> “System” and press  , then select “Others” and press  again;

3. Set “Power Save” item as ON, so as to activate it;

3.11 Keyboard Lock And Unlock

Press  +  to lock the keyboard.

When keyboard locked, only ON/OFF button and "Shift+9" operations are valid, the other key operations are invalid. At the same time, the parameter setting area in MAIN PAGE will shown in gray color to differentiate with normal unlocked state.

To unlock the keyboard, press  +  again.

3.12 Sequence (SEQ) Function

For sequence test function, the corresponding menu option is "Sequence". The sequence feature allows users to program a list of steps to the power supply's internal memory and execute them. A total of 100 steps can be allocated to each internal memory location, up to a maximum of 10 locations (sequences files). Voltage, current and delay can be set in each step. Sequence file supports "cycle" and "link" attributes. "cycle" controls the sequence file to run cyclically for a specified times, set to 0 means infinite loop. "Link" can add other sequence file into test, set to 0 means no linked sequence file.


When the sequence test is turned on, the highest voltage and current slew rate are used by default.


Table 3-4 Sequence Parameter Explanation

Parameter	Explanation
Length	SEQ file running steps, range 1 ~ 100
Cycle	Set SEQ file running cycles, range 0 ~ 60000, value 0 means infinite cycle. Default value is 1.
Link	Range 0 ~ 10, call specified SEQ file to run at this step, value 0 means no linked file
SEQ Step	Choose the specified step to edit. Range 0 ~ 100
V_Set	Output voltage for current step, Range 0 ~ max. Output voltage
I_Set	Output current for current step, Range 0 ~ max. Output current
Step-Time	Delay for current step, range 0.001 ~ 86400s. The delay time is counting from the moment that the current step V/I reaches the setting value.

Program Sequence (SEQ):










1. Press  ;

2. Select "Edit" >> "Sequence" press  to enter sequence file choosing page;

3. Rotate the rotary knob or input numbers to choose a file for editing, press  to enter SEQ editing page:

Set	System	Edit	About
SEQ Step	1	File Length	<u>100</u>
V_Set	0.000 V	Cycle	1
I_Set	0.000 A	Link	0
Step-Time	86400.0 s		



Figure 3-13 Sequence File Edit

4. Set "Length", press  to validate it, the editing cursor will move to "Cycle" automatically;
5. Set "Cycle", press  to validate it, the editing cursor will move to "Link" automatically;
6. Set "Link", press  to validate it, the editing cursor will move to "SEQ Step" automatically;
7. Set "SEQ Step", press  to validate it, the editing cursor will move to "V_Set" automatically;
8. Set "V_Set", press  to validate it, the editing cursor will move to "I_Set" automatically;
9. Set "I_Set", press  to validate it, the editing cursor will move to "Step-Time" automatically;
10. Set "Step-Time", press  to validate it, the editing cursor will move to "SEQ step" automatically;
11. Repeat procedures of 7 ~ 11, till all sequence steps have been programmed.
12. Press  to save the programmed sequence file.
13. Press  to quit sequence editing.



Notice When output is ON, sequence editing is not allowed.

Running sequence file

1. Press  to enter test function selecting page;
2. Rotate the rotary knob to select "Sequence", press  to activate sequence test, the screen will displays:






Figure 3-14 Sequence Test Display

3. Set "Run File", press  to validate it;
 4. Press  to start sequence test.
- About the display information: "Step:" shows the current sequence step, "Cycle:" shows how many cycles the sequence have run.

3.13 Internal Resistance Simulation (RESI)

Since a battery has internal resistance, its output voltage will decrease along with the increasing output current. FTP9000 series power supply provides internal resistance simulation feature to imitate the output characteristics of batteries. With this function, the power supply output voltage satisfy below formula:

$$V_0 = V_s - I_0 \times R_{Inner}$$


V_0 : Actual output voltage;



V_s : Theoretical output voltage;

I_0 : Output current;

R_{Inner} : simulated Inner resistance.

Operation:

1. Press  to enter test modes selection interface;

2. Use "Rotary"  knob to select "RESI", press  , the screen displays as below:





Figure 3-16 Output Test For Battery Simulating


3. Set the corresponding test parameters;
4. Press  to turn on battery simulating output.




Table 3-5 RESI Test Parameter Explanation

Parameter	Notes
Max Volt	RESI simulating output max voltage
Max Curr	RESI simulating output max current
Max Pow	RESI simulating output max power
IR-Set	RESI simulating battery inner resistance

3.14 Voltage ramp-up, ramp-down (RAMP)

FTP9000 series power supply allows for output voltage ramp-up and ramp-down according to the set slew rate.

Operation:

1. Press  to enter test modes selection interface;
2. Use "Rotary"  knob to select "RAMP", press , the screen displays as below:






Figure 3-17 RAMP Function Parameter Set


3. Set the corresponding parameters, you can refer to "Table 3-6 RAMP Function Parameter Explanation" ;
4. Press  to turn on voltage ramp output.

Table 3-6 RAMP Function Parameter Explanation

Parameter	Explanation
Ua	Set voltage for A, range: 0 - Max output voltage
Ub	Set voltage for B, range: 0 - Max output voltage
Uc	Set voltage for C, range: 0 - Max output voltage
Slew AB	Set voltage slew rate from A to B, range: 0.0006V/s to 6000V/s, default value 50% max slew rate
Slew BC	Set voltage slew rate from B to C, range: 0.0006V/s to 6000V/s, default value 50% max slew rate
I_Set	Set output current, range: 0 - Max output current
P_Set	Set output power, range: 0 - Max output power




Figure 3-18 RAMP Function Parameter Set

3.15 Master-slave Parallel

3.15.1 Master-slave parallel connection

FTP9000 series power supplies provide a master-slave parallel mode, so that users can achieve greater output power by paralleling same models. The user uses proper wires to connect the "Share" interface in the rear panel, the "RS485" parallel communication interface in the "PRO-INT" port, and the output positive and negative poles according to "Figure 3-19 Master-Slave Parallel Connection", and then make corresponding configuration for the power supplies to realize the master-slave parallel function, operating the whole group is as simple as operating a stand-alone power supply.




Figure 3-19 Master-Slave Parallel Connection

Master-slave parallel cable requirements



It is OK to use cross-sectional area 0.5 mm² ~ 1 mm² double strand wire for RS485 and “Share” ports.

CAUTION

1. Master-slave parallel support identical power supplies only;
2. Max 10 units;
3. Use the V SENSE terminal of the master unit if you want to compensate voltage line loss;
4. Does not support master-slave series operation

3.15.2 Master-slave parallel setting



Slave setting


1. Press  to enter main menu interface;
2. Select “Set” >> “Parallel”, then press  to display master-slave parallel setting page;
3. “M_or_S” item set as “Slave1”, “Slave2”... etc., one number corresponds to one slave power supply, number starts from 1 and must be consecutive, repeat numbers are forbidden because it leads to communication error.
4. Unwanted configuration items are hidden when a slave power supply returns to main display page.

Master setting

Set	System	Edit	About
M_or_S	Master		
S.NUM	1		
MS_CTRL	OFF		

Figure 3-20 Master-Slave Parallel Set

1. Press  to enter main menu interface;
2. Select "Set" >> "Parallel", then press  to display master-slave parallel set page;
3. "M_or_S" item set as "Master";
4. "S.NUM" item set as the actual number of slave power supplies;
5. "MS_CTRL" item as as "ON".

Press  to return to main page after completing the parallel parameter setting. The master power supply specifications will be updated.

3.15.3 Master-slave parallel function operations

Simply operate the master unit to control the whole group if you have configured the master-slave parallel correctly. The relative protections are still in effect once parallel function is turned on. The system will automatically turn off all power outputs if one unit in the group is protected. The corresponding slave unit displays the specific fault information, and the master unit displays the master fault information and the fault slave code, as shown in the figure below:




Figure 3-21 Master display




Figure 3-22 Slave display






When a protection occurred in the slave unit, please press  to clear fault in corresponding slave unit and in master unit. When protection occurred in master unit only, just press  on master unit to clear fault. Possible protections and fault in parallel operations are listed as follows:

Table 3-7 Master-slave parallel protection

Protection Display	Explanation
Σ -P	Parallel communication normal, symbol is white background and not blinking
	Parallel communication error, symbol is red background and blinking
	Indicates the fault slave unit code, requires user to press  to clear the fault protection

**CAUTION**

1. Set slave unit first, so as to avoid master unit communication error;
2. Multiple power supplies have been set as master unit leads to parallel operation failure;
3. If cable in "Share" port is not connected or fall off, then although the specifications are updated in accordance with number of slave units when the master unit turns on master-slave parallel control, the actual output will be inconsistent with the master unit configuration due to "Share" port fault.
4. The external programming of the master unit is effective to the whole group.
5. When a power supply is configured as slave unit, the previous set protection value in "Protection" are canceled. To resume you have to reset its values.
6. It is prohibited for paralleling different power supply models, because this will damage the power supplies.

3.16 Photovoltaic Simulation Function (PV-SIM) (Optional)

FTP9000 series products have the function of photovoltaic analog power supply to establish maximum power point tracking (MPPT), and can set curve mode and user-defined mode according to the application scene, mainly used for photovoltaic array/module/battery MPPT test. Photovoltaic array/module/cell is mainly a device to convert light energy into electric energy, mainly with a simple semiconductor PN interface. The main output characteristics of the PN interface are: under certain lighting conditions, there is only one maximum power point (MPP), and the use of this function can track the MPP to harvest the maximum power generated by the photovoltaic group.


Table 3-8 Parameters of the PV curve

Parameter name	Parameter description
File number	File serial number for PV operation, ranging from 1 to 20.
PMP	Maximum power of the PV curve, ranging from 0 to maximum source power.
VMP	The voltage value of the maximum power of the PV curve, ranging from 0 to maximum voltage.
Laws and regulations	Supports SANDIA and EN50530.
material	SANDIA material options for TF, SCMC, HEC; EN50530 material options for TF, CSI.

Edit PV file






1. Press  button, Enter the menu setting interface;

2. Select "Edit" -> "PV File", press  key to Enter the PV file selection screen;

3. Turn the knob or enter a number to select the file number you want to edit, press  key to Enter the edit file screen;

Setting	system	Edit	About
PMP	0 W	VMP	60000 V
Regulation	SANDIA		
Material	TF		

Figure 3-23 photovoltaic file editing screen



4. set"PMP", press  key to confirm, Edit focus moves to the next item"VMP";
5. set"VMP", press  key to confirm, Edit focus moves to the next item"Regulation";
6. Set"Regulation", press  key to confirm, Edit focus automatically moves to the next item"material";
7. press  key, Save the photovoltaic curve file you just edited;
8. Press  key, Exit the photovoltaic file editing screen.

Note: It is not allowed to edit PV files when the device is on.



Run PV simulation mode

Menu PV simulation Mode Settings Operation Settings:

The user's photovoltaic operation type selection operation is as follows:

1. press  key, Enter the Menu menu Settings interface, and select Application Settings in the Settings options;
2. Application Settings -> PV Mode, press  Scroll the knob to select the desired configuration option Curve or Define.

Steps of operation

1. press  key, Enter the Test function selection screen;
2. Roll knob, select"PV-SIM", press  key to Enter the "PV-SIM" user-defined function parameter setting screen as follows:




Figure 3-24 Photovoltaic file custom editing screen

3.Set“PV-SIM”Functional parameter , Parameter description such as error! Reference source not found.;


4.Press  key to Turn on charging, press again  key, Will stop discharging, Zero the power and time at the same time.

Table 3-9 User-defined parameters of the PV function

Parameter name	Parameter description
VOC	Open circuit voltage set value, range: 0 ~ maximum voltage value
IMP	Maximum power current set value, range: 0 ~ maximum current value
VMP	Maximum power voltage set value, range: 0 ~ maximum voltage value
Short-circuit current	Range: 0 to maximum current value
Maximum voltage	Range: 0 ~ maximum voltage value

Table 3-10 Parameters of the PV function curve mode


Parameter name	Parameter description
----------------	-----------------------

File number	Run file number, range: 1 to 20
VLMT	Range: 0 to the maximum voltage
Filtering speed	Range: Slow,MIDD,Fast

4. Communication Introduction

FTP9000 series power supply provides users with 5 types of communication interfaces: standard USB (serial), LAN (Ethernet), optional GPIB or CAN or RS485 interfaces. FTP9000 supports standard Modbus, SCPI protocol, default protocol is ModBus. Users are able to configure communication ports and protocols base on requirements.

4.1 Communication Setup

1. Press  to enter main menu page;

2. Select "System">>"Communication ", press  to pop up system parameter setting page as below:

Set	System	Edit	About
IP	192.168.1.123		
S_Mask	255.255.255.0		
Baud	9600		
Parity	None	Protocol	Modbus
DEVI-ADDR	160		
R			
GPIB	5		

Figure 4-1 Communication Parameter Setting Interface

3. For LAN communication: first please set "IP" as 192.168.1.123, subnet mask as 255.255.255.0, then set the IP address of the connecting PC to be in the same segment with the power supply IP. Different IP segments will result in communication failure. For example, computer network IP "192.168.1.100" is OK while "198.168.1.100" is not OK.

4. For USB communication: First please set "Baud", default value 9600, configurable among 4800, 9600, 19200, 38400, 115200. Then set "Parity" as "None".

5. For RS485 communication: First please set "Baud", default value 9600, configurable among 4800, 9600, 19200, 38400, 115200. Then set "Parity" as "None", "DEVI-ADDR" default value 160, range 0 ~ 254.

6. For CAN communication: set "DEVI-ADDR", default value 160, range 0 ~ 254 (Device address).

7. For GPIB communication: set "GPIB", default value 5, range 0 ~ 30 (GPIB address).

8. Set communication protocol, select ModBus or SCPI.

After modifying the communication configuration, you need to restart the power supply to take effect.




CAUTION

After modifying the communication configuration, you need to restart the power supply to take effect.

4.2 Voltage, current acquisition speed

After the above communication configuration is completed, if the user needs to increase the voltage, current acquisition speed, the configuration can be as follows:

1. Press  to enter main menu page;
2. Select "Set" >> "App Set", press  to show as below:

Set	System	Edit	About
Samp Rate	10Hz		
Prio SLT	Volt		
V _{slew-UP}	5000.0	V/s	
V _{slew-DN}	5000.0	V/s	
I _{slew-UP}	2000.0	V/s	
I _{slew-DN}	2000.0	V/s	

Figure 4-2 Application Setting

3. Select required speed in "Samp Rate", there are 5 choices select-able, Default is 10Hz.

4.3 Communication Interfaces

4.3.1 USB (Serial)

FTP9000 provides a USB virtual serial port, compatible with Windows XP/7/8/10. For specific driver software and installation, please refer to the "CD and Software User Manual".

The USB port uses a baud rate of 9600bps by default, parity type is None, and does not support flow control. Also, it adopts USB-B type terminal, users can use the accessory USB communication cable to easily connect to the USB port on the PC. Its pin signals are described in the following table:

Table 4-3 USB Interface Signals

Pin NO.	Description
1	5V DC
2	Data-
3	Data+
4	GND

4.3.2 LAN

The FTP9000 series power supply has an Ethernet communication interface and adopts UDP communication mode. The default IP address is 192.168.1.123, the default subnet mask is 255.255.255.0, and the default port number is 7000.

**CAUTION**

Before starting communication, make sure that the address of the PC and the power supply are in the same network segment, and that there is no duplicate IP address with the power supply in this network segment, otherwise it will not be able to connect correctly.

4.3.3 CAN

The CAN interface uses a fixed communication speed of 500kbps, and the communication address can be set from 0 to 255.




Figure 4-3 CAN communication connections

**Notice**

CAN interface uses CANopen protocol.

4.3.4 RS485

The RS485 communication interface configuration is the same as that of the USB serial port. The baud rate and parity method can be configured through "Figure 4-1 Communication Parameter Setting Interface". The connection method is as follows:




Figure 4-4 RS485 communication connections

4.4 Communication Protocol


FTP9000 series power supplies support SCPI, Modbus and CANopen communication protocols. For LAN, USB serial port, RS485 interface, users can choose SCPI or Modbus; for GPIB interface, only SCPI protocol is supported, and CAN interface only supports CANopen protocol.

4.4.1 SCPI protocol

Standard Commands for Programmable Instruments Standard Commands for programmable Instruments SCPI is a standardized instrument programming language based on the existing standards IEEE488.1 and IEEE 488.2, and follows the floating-point arithmetic rules of IEEE754 standard, ISO646 information exchange 7-bit coded symbol (equivalent to ASCII programming) and other standards. It adopts a tree-like hierarchical command set, proposes a universal instrument model, and uses signal oriented measurement. Its mnemonic generation rules are simple, clear, and easy to remember.

Power commands are classified into two types: IEEE488.2 public commands and device-related SCPI commands.

IEEE 488.2 Common Commands define a number of control and query commands common to instrumentation. You can use public commands to perform basic operations on the power supply, such as reset and status query. All IEEE 488.2 public commands consist of "" and three-letter mnemonics, such as: *RST, *IDN?, *ESE? Etc. SCPI commands are used to test, set, calibrate, and measure the power supply. This type of command is organized as a command tree. Each command can contain multiple mnemonics. Nodes of the command tree are separated by the character: (:), as shown in the following figure. The ROOT at the top of the command tree is called the root. The full path from root to leaf is a complete programming command.



For details of SCPI protocol, please refer to 《FTP9000 Programming Manual SCPI Edition》.

4.4.2 Modbus protocol

Modbus is a serial communication protocol published by Modicon (now Schneider Electric) in 1979 for communication using Programmable logic controllers (PLCS). Modbus has become the De facto standard for industrial communication protocols and is a common connection between industrial electronic devices. Modbus is a master/slave protocol. One node is a master node, and the other nodes that participate in communication using Modbus protocol are slave nodes. Each slave device has a unique address. Only the node designated as the master node can start a command.

A Modbus command contains the Modbus address of the device to be executed. All devices receive the command, but only the device at the specified address executes and responds to the instruction. (The exception is address 255, where the instruction at address 255 is a broadcast instruction, and all devices receiving the instruction run but do not respond to the instruction.) All Modbus commands contain a check code to determine that the arriving command is not broken. Basic Modbus commands can direct a device to change its register values, control or read an I/O port, and direct the device to send back data in one or more registers.



Regarding to ModBus protocol, FTP9000 series support RTU communication mode only.

For details about the Modbus protocol, refer to 《FTP9000 Programming Manual Modbus Edition》.

4.4.3 CANopen protocol

CANopen is a kind of high-level communication protocol on Controller Area Network (CAN), including communication sub-protocol and equipment sub-protocol, and is a field bus commonly used in industrial control. CANopen implements protocols above the network layer (including the network layer) in the OSI model. The CANopen standard includes an addressing scheme, several small communication subprotocols, and an application layer defined by the device subprotocols. CANopen supports network management, device monitoring, and internode communication, including a simple transport layer that handles segmented transfer and combination of data. Generally speaking, the data link layer and physical layer will be implemented using CAN.



CANopen protocol is an optional protocol.

For details of CANopen protocol, please refer to 《FTP9000 Programming Manual CANopen Edition》.

5. Troubleshooting

Follow the actions described in this chapter to inspect the instrument and troubleshoot the problem if the FTP9000 series DC Power Supply does not operate normally. Contact Faithtech authorized agent or Faithtech after-sales if the information provided in this manual does not resolve the problem.

Table 5-1 Fault Check






Problem	Possible Cause	Solution
Measurement accuracy is not within SPEC.	Measurement swings due to aged components.	Do calibration.
Output accuracy is not within SPEC.	Output swings due to aged components.	Do calibration
PMF Fault	1. The grid power supply is below the instrument requirement; 2. 2. PMF triggered by power failure	1. Check whether the grid power supply is normal 2. 2. Neglectable if PMF triggered by power failure 3. Press  to clear protection state.
Overtemperature Protection (OTP1、OTP2)	1. The ambient temperature is too high. 3. Bad ventilation. 4. Fan damaged.	1. Operate the instrument within an ambient temperature of 0 - 40°C. 2. Ensure the instrument is well ventilated. 3. Contact Faithtech authorized agent or Faithtech after-sales. 4. Press  to clear protection state.
Overpower Protection (OPP, OP)	The output power exceeds the spec. or OPP settings.	1. Decrease load or increase OPP setting. 2. Press  to clear protection state.
Overcurrent Protection (OCP, OC)	The output current exceeds the spec. or OCP settings.	1. Decrease load or increase OCP setting. 2. Press  to clear protection state.
Overvoltage Protection (OVP, OV)	The output voltage exceeds the spec. or OVP settings.	1. Decrease output voltage or increase OVP setting. 2. Press  to clear protection state.

Table 5-2 Power on Self-test Fault Check

Problem	Possible Cause	Solution
The PRI Fault... Error!	Internal communication error Power module error	Contact Faithtech after-sale service
Test sample. Error!	Sampling data error	
Loading calibration data. Error!	Loading calibration data failure	
Loading parameters. Error!	Loading system para failure	

6. Appendix

Table 6-1 Recommended Wire Diameters for Cables

Type	Cross-sectional area	Different temperature conditions			
AWG	mm ²	60℃	75℃	85℃	90℃
		Wire type: RUW, T, UF	Wire type: RHW, RH	Wire type: V, MI	Wire type: TA, TBS, SA, AV
		Rated Current (A)			
14	2.08	20	20	20	20
12	3.31	25	25	30	30
10	5.26	30	35	40	40
8	8.36	40	50	55	55
6	13.3	55	65	70	75
4	21.1	70	85	95	95
3	26.7	85	100	110	110
2	33.6	95	115	125	130
1	42.4	110	130	145	150
0	53.5	125	150	165	170
00	67.4	145	175	190	195
000	85	165	200	215	225
0000	107	195	230	250	260

Shenzhen Faithtech CO., LTD.

ADD: 3C, Building 1, Saitu Digital Industrial Park, No.137 Bulan Road, Longgang District, Shenzhen, China

Tel: (0086) 15817482598

Website: <https://en.faithtech.cn>