



Atmel ATSAM21G18A Programming Cable

Notes:

Use Atmel Studio

Select Tools\DeviceProgramming

Device is ATSAM21G18A

Remember to set Target Power On in J-Link Control Panel if required

Use the Fuses tab to set NVMCTRL_BOOTPROT to 0x07 before programming