



CityGML Package Diagram



Usage of ISO and OASIS standards in CityGML



Color Scheme


Class defined in this
Requirements Class

Class defined in another
Requirements Class


Class defined in ISO 19107,
ISO 19111 or ISO 19123

Class defined in ISO 19109


Notes and OCL constraints




Core module - Space concepts




Core - Geometry and LoD concept




Core module - City object relations




Core module - Miscellaneous




Core module - Basic Types, Enumerations, and Code lists




Core module - ADE Data types




Appearance module




Appearance module - ADE Data types







Bridge module - Code lists




Bridge module - ADE Data types




Building module




Building module - Code lists



Building module - ADE Data types



CityFurniture module




CityFurniture module - Code lists

«CodeList»
CityFurnitureClassValue


«CodeList»
CityFurnitureFunctionValue

«CodeList»
CityFurnitureUsageValue

CityFurniture module - ADE Data types



CityObjectGroup module




CityObjectGroup module - Code lists

«CodeList»
CityObjectGroupClassValue


«CodeList»
CityObjectGroupFunctionValue

«CodeList»
CityObjectGroupUsageValue


CityObjectGroup module - ADE Data types




Construction module




Construction module - Code lists



Construction module - ADE Data types





Dynamizer module - Code lists


«CodeList»
SensorConnectionTypeValue

«CodeList»
TabulatedFileTypeValue


«CodeList»
StandardFileTypeValue

«CodeList»
AuthenticationTypeValue

Dynamizer module - ADE Data types



Generics module



Generics module - Code lists

«CodeList»

GenericLogicalSpaceClassValue

«CodeList»

GenericOccupiedSpaceClassValue

«CodeList»

GenericUnoccupiedSpaceClassValue

«CodeList»

GenericLogicalSpaceFunctionValue

«CodeList»

GenericOccupiedSpaceFunctionValue

«CodeList»

GenericUnoccupiedSpaceFunctionValue

«CodeList»

GenericLogicalSpaceUsageValue

«CodeList»

GenericOccupiedSpaceUsageValue

«CodeList»

GenericUnoccupiedSpaceUsageValue

«CodeList»

GenericThematicSurfaceClassValue


«CodeList»

GenericThematicSurfaceFunctionValue


«CodeList»

GenericThematicSurfaceUsageValue

Generics module - ADE Data types



LandUse module



LandUse module - Code lists

«CodeList»

LandUseClassValue


«CodeList»

LandUseFunctionValue


«CodeList»

LandUseUsageValue


LandUse module - ADE Data types




PointCloud module





PointCloud module - ADE Data types





Relief module - ADE Data types







(from Core)

Transportation module - Code lists


«CodeList» TrafficSpaceClassValue	«CodeList» TrafficAreaClassValue	«CodeList» AuxiliaryTrafficSpaceClassValue	«CodeList» AuxiliaryTrafficAreaClassValue	
«CodeList» TrafficSpaceFunctionValue	«CodeList» TrafficAreaFunctionValue	«CodeList» AuxiliaryTrafficSpaceFunctionValue	«CodeList» AuxiliaryTrafficAreaFunctionValue	
«CodeList» TrafficSpaceUsageValue	«CodeList» TrafficAreaUsageValue	«CodeList» AuxiliaryTrafficSpaceUsageValue	«CodeList» AuxiliaryTrafficAreaUsageValue	
«CodeList» ClearanceSpaceClassValue	«CodeList» SectionClassValue	«CodeList» HoleClassValue	«CodeList» SurfaceMaterialValue	
	«CodeList» IntersectionClassValue	«CodeList» MarkingClassValue		
«CodeList» TrackClassValue	«CodeList» RoadClassValue	«CodeList» WaterwayClassValue	«CodeList» RailwayClassValue	«CodeList» SquareClassValue
«CodeList» TrackFunctionValue	«CodeList» RoadFunctionValue	«CodeList» WaterwayFunctionValue	«CodeList» RailwayFunctionValue	«CodeList» SquareFunctionValue
«CodeList» TrackUsageValue	«CodeList» RoadUsageValue	«CodeList» WaterwayUsageValue	«CodeList» RailwayUsageValue	«CodeList» SquareUsageValue

Transportation module - ADE Data types







Tunnel module - Code lists



Tunnel - ADE Data types



Vegetation module



Vegetation module - Code lists

«CodeList»
SolitaryVegetationObjectClassValue

«CodeList»
SolitaryVegetationObjectFunctionValue

«CodeList»
SolitaryVegetationObjectUsageValue

«CodeList»
PlantCoverClassValue

«CodeList»
PlantCoverFunctionValue

«CodeList»
PlantCoverUsageValue


«CodeList»
SpeciesValue

Vegetation module - ADE Data types

«DataType»
ADEOfAbstractVegetationObject

«DataType»
ADEOfSolitaryVegetationObject

«DataType»
ADEOfPlantCover



Vegetation module - Code lists

«CodeList»
SolitaryVegetationObjectClassValue

«CodeList»
SolitaryVegetationObjectFunctionValue

«CodeList»
SolitaryVegetationObjectUsageValue


«CodeList»
PlantCoverClassValue

«CodeList»
PlantCoverFunctionValue


«CodeList»
PlantCoverUsageValue

«CodeList»
SpeciesValue

Versioning module - ADE Data types



WaterBody module



WaterBody module - Code lists

«CodeList»
WaterBodyClassValue

«CodeList»
WaterLevelValue

«CodeList»
WaterBodyFunctionValue

«CodeList»
WaterBodyUsageValue

WaterBody module - ADE Data types

