

**FEITIAN**

# bR301 Driver Install Manual For Windows



## Revision History:

Date	Revision	Description
May 22, 2014	V1.0	Release of the first version
Oct 19, 2015	V2.0	Release the second version
Nov 11, 2015	V2.1	Add driver uninstall contents

## Software Developer's Agreement

All Products of Feitian Technologies Co., Ltd. (Feitian) including, but not limited to, evaluation copies, diskettes, CD-ROMs, hardware and documentation, and all future orders, are subject to the terms of this Agreement. If you do not agree with the terms herein, please return the evaluation package to us, postage and insurance prepaid, within seven days of their receipt, and we will reimburse you the cost of the Product, less freight and reasonable handling charges.

1. Allowable Use – You may merge and link the Software with other programs for the sole purpose of protecting those programs in accordance with the usage described in the Developer's Guide. You may make archival copies of the Software.
2. Prohibited Use – The Software or hardware or any other part of the Product may not be copied, reengineered, disassembled, decompiled, revised, enhanced or otherwise modified, except as specifically allowed in item 1. You may not reverse engineer the Software or any part of the product or attempt to discover the Software's source code. You may not use the magnetic or optical media included with the Product for the purposes of transferring or storing data that was not either an original part of the Product, or a Feitian provided enhancement or upgrade to the Product.
3. Warranty – Feitian warrants that the hardware and Software storage media are substantially free from significant defects of workmanship or materials for a time period of twelve (12) months from the date of delivery of the Product to you.
4. Breach of Warranty – In the event of breach of this warranty, Feitian's sole obligation is to replace or repair, at the discretion of Feitian, any Product free of charge. Any replaced Product becomes the property of Feitian.

Warranty claims must be made in writing to Feitian during the warranty period and within fourteen (14) days after the observation of the defect. All warranty claims must be accompanied by evidence of the defect that is deemed satisfactory by Feitian. Any Products that you return to Feitian, or a Feitian authorized distributor, must be sent with freight and insurance prepaid.

EXCEPT AS STATED ABOVE, THERE IS NO OTHER WARRANTY OR REPRESENTATION OF THE PRODUCT, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

5. Limitation of Feitian's Liability – Feitian's entire liability to you or any other party for any cause whatsoever, whether in contract or in tort, including negligence, shall not exceed the price you paid for the unit of the Product that caused the damages or are the subject of, or indirectly related to the cause of action. In no event shall Feitian be liable for any damages caused by your failure to meet your obligations, nor for any loss of data, profit or savings, or any other consequential and incidental damages, even if Feitian has been advised of the possibility of

damages, or for any claim by you based on any third-party claim.

6. Termination – This Agreement shall terminate if you fail to comply with the terms herein. Items 2, 3, 4 and 5 shall survive any termination of this Agreement.


## Contents

1. Install driver on Windows 7 .....	4
1.1 Install and uninstall driver.....	4
1.2 Pair your bR301 with your PC .....	5
1.3 Using and test .....	6
2. Install driver on Windows 8 and Windows 10.....	7
2.1 Install and uninstall driver.....	7
2.2 Pair your bR301 with your PC .....	8
2.3 Using and test .....	8
3. Uninstall bR301 driver.....	9
4. Using bR301 with Bluetooth connection in VMware.....	10
5. FAQ when using bR301 on Windows.....	11


## 1. Install driver on Windows 7

### 1.1 Install and uninstall driver

1. before install driver, please make sure there no bR301 paired with your PC, to confirm this, please check your “connected device”, and see below picture, removed paired reader:




2. The new driver will check system version by itself, customer just need using administrator to install and uninstall



## 1.2 Pair your bR301 with your PC

1. Press power button to power on reader and to do pair with your PC




Confirm the reader has connected with PC correctly by Bluetooth. The blue LED light shines twice per 0.5 second when not pairing

## 1.3 Using and test

1. Using “FEITIAN test tool” to do test. When you insert your card, the white light will turn on.

Using FEITIAN test tool, you can chose send single command or script to do test.

Here is example using FEITIAN script with FEITIAN JAVA card. Chose “Open Script”, and click start to do test. The “Write” button means write all test data into log.



### NOTICE:


Every time when you do reboot your computer, please open bR301 at first, because the driver need be load when bR301 paired with PC correctly.




## 2. Install driver on Windows 8 and Windows 10

### 2.1 Install and uninstall driver

1. Same like win 7, using administrator run install file, choose YES means install, No means uninstall




2. One more thing, un-pair your bR301 from PC



## 2.2 Pair your bR301 with your PC


1. Press power button on bR301, to do search bR301 and pair with your PC.



## 2.3 Using and test


1. Using “FEITIAN test tool” to do test. When you insert your card, the white light will turn on.

Using FEITIAN test tool, you can chose send single command or script to do test. Here is example using FEITIAN script with FEITIAN JAVA card. Chose “Open Script”, and click start to do test. The “Write” button means write all test data into log.




### 3. Uninstall bR301 driver

To uninstall driver, please uninstall at device manager, open device manager, and choose bR301 smart card reader driver-> uninstall




## 4. Using bR301 with Bluetooth connection in VMware

1. Some customer want using bR301 in vmware, to implement this, you will need connect your Bluetooth adapter into VMware



2. Don't using share mode, in vmware setting, keep "Share Bluetooth devices with the virtual machine" not selected



## 5. FAQ when using bR301 on Windows

1. Do we need pair bR301 before install driver?

[A] For the new driver, don't need pair your bR301 before install driver, the driver will automatically detect your bR301 after install driver.

2. Is possible using two bR301 with Bluetooth connection on Windows?

[A] The current driver we only support one bR301, please donot using two bR301 with Bluetooth connection, our driver only support first one.

3. Is possible using Bluetooth connection on Linux and Mac OS X?

[A] Yes, it is possible also do support on Mac OS X, but we haven't make yet, if you have such requirements, please send mail to us. [ben@ftsafes.com](mailto:ben@ftsafes.com)


4. Sometimes, I saw the reader is doing flashing and card doesn't being detect, how to solve this problem?

[A] Please confirm only have one bR301 connected to your PC, if yes, please plug-out battery and put it again to check. If the problem still exist, please send mail to Feitain [ben@ftsafes.com](mailto:ben@ftsafes.com)

5. My computer (Win 8 and Win 10) have one more bR301 connected, but I cannot remove it on, could you please help on this?

[A] It is a problem on Window, the Bluetooth protocol stack doesn't release Bluetooth device, please follow below to do operation"

a. Win+x, open "Device Manager", select "Show hidden devices",



b. It will show all connected bR301 device, you can select your specific device to do uninstall.

