

# Set IP Address

Ip configuration guide



## ✓ Static IP Setting

Baikal Miner IP Configurator

Option

Target Drive : D: ☐ Auto

Mode

☒ Write ☐ Read

IP Setting

☐ DHCP ☒ STATIC

☒ Auto Increment IP Address

IP Address : 192 . 168 . 0 . 134

Network Mask : 255 . 255 . 255 . 0

Gateway : 192 . 168 . 0 . 0

DNS 1 : 192 . 168 . 0 . 0

DNS 2 : 0 . 0 . 0 . 0

DNS 3 : 0 . 0 . 0 . 0

Write Exit

- ① Select Drive which SD card assigned.
- ② Choose STATIC for the static IP address.
- ③ Select Write for the mode.
- ④ Enter IP address.
- ⑤ Enter Network Mask.
- ⑥ Enter Gateway.
- ⑦ Enter DNS Server address.
- ⑧ Click on Write button to complete static IP setting.
- ⑨ 'Save Static IP : x.x.x.x : Okay' on the right screen indicates the desired IP address has been set successfully.

**\*Note\***

Auto Increment IP Address : helps you to get increasing numbers one after another SD card automatically. Helpful when you are dealing with number of SD cards.

## ✓ DHCP Setting

Baikal Miner IP Configurator

Option

Target Drive :  ☐ Auto

Mode

☒ Write ☐ Read

IP Setting

☐ DHCP ☒ STATIC

☒ Auto Increment IP Address

IP Address :

Network Mask :

Gateway :

DNS 1 :

DNS 2 :

DNS 3 :

- ① Select Drive which SD card assigned.
- ② Choose DHCP for the dynamic IP address.
- ③ Select Write for the mode.
- ④ Enter IP address.
- ⑤ Enter Network Mask.
- ⑥ Enter Gateway.
- ⑦ Enter DNS Server address.
- ⑧ Click on Write button to complete DHCP IP setting.
- ⑨ 'Save DHCP : Okay' on the right screen indicates the IP address has been set as DHCP successfully.

## ✓ Download Link

<http://pan.baidu.com/s/1dFg9rZ7>